



## HPS30

### Hybrid Energy System

### User Manual

#### **SHENZHEN ATESS POWER TECHNOLOGY CO.,LTD**

GROWATT-ATESS Industrial Park, No.23 Zhulongtian Road, Shuitian Community,  
Shiyan Street, Baoan District, Shenzhen

Tel: +86 755 2998 8492

Web: [www.atesspower.com](http://www.atesspower.com)

Email: [info@atesspower.com](mailto:info@atesspower.com)

Revised date: 2024-05-09

# Contents

## 1 Introduction

- 1.1 Contents
- 1.2 Target readers
- 1.3 Symbols

## 2 Safety Instructions

- 2.1 Notice for use
- 2.2 Installation
- 2.3 Important note

## 3 Product Description

- 3.1 Energy storage system
- 3.2 Circuit diagram of the inverter
- 3.3 Layout of the main components
- 3.4 Operation mode and status
- 3.5 Function protection
- 3.6 Dimension
- 3.7 Packing information

## 4 Transportation and Storage

- 4.1 Transportation
- 4.2 Inspection and storage

## 5 Product Installation

- 5.1 Installation condition and requirements
- 5.2 Tools and spare parts required for whole machine installation
- 5.3 Mechanical installation
- 5.4 Electrical installation
- 5.5 Communication
- 5.6 ATS wiring
- 5.7 DG dry contact connection
- 5.8 Parallel connection

## 6 Pilot operation

- 6.1 Inspection
- 6.2 Commissioning

## 7 GUI instruction

- 7.1 LCD display screen introduction
- 7.2 LCD operation
- 7.3 LCD display information schedule

## 8 Operation

- 8.1 Power on steps
- 8.2 Pilot operation completion
- 8.3 General history failure table
- 8.4 Power off steps

## 9 Product Maintenance

- 9.1 Regular maintenance
- 9.2 Waste disposal

## 10 Appendix

- 10.1 Specification
- 10.2 Factory warranty
- 10.3 Maintenance and inspection checklist for running system
- 10.4 Maintenance and inspection checklist for shutdown system
- 10.5 EMS mode RS485 command

# 1 Introduction

## 1.1 Contents

This manual will provide detailed product information and installation instructions for HPS series energy storage integrated inverter (hereinafter referred to as inverter). Please read this manual carefully before using the product and store it in a place convenient for installation, operation and maintenance. Users will not be informed of any modification of this manual. The contents of the manual will be updated and revised constantly, and it is inevitable that there is a slight discrepancy or error between the manual and the real product, Please refer to the actual products that you have purchased. Users should contact their local distributors or log in to our website to download and obtain the latest version of the manual.







## 1.2 Target readers

Qualification:

- Only professional electricians certified by relevant departments can install this product.
- The operator should be fully familiar with the structure and working principle of the entire energy storage system.
- The operator should be fully familiar with this manual.
- The operator should be fully familiar with the local standards of the project.

## 1.3 Symbols

In order to ensure the personal and property safety of the user during installation, or optimally efficient use of this product, symbols are used highlight the information. The following symbols may be used in this manual, please read carefully, in order to make better use of this manual.

|                                                                                     |                                                                                                                                                                                                                          |
|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <b>DANGER</b><br>DANGER indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.                                                                                      |
|  | <b>CAUTION</b><br>CAUTION indicates there is potential risk, if not avoided, could result in equipment malfunction and property damage.                                                                                  |
|  | <b>Caution, risk of electric shock</b><br>When battery bank connecting point are exposed, there will be DC voltage in the equipment DC side; and when output breaker is on, there is a potential risk of electric shock. |
|  | <b>Caution, risk of fire hazard</b><br>Suitable for mounting on concrete or other non-combustible surface only.                                                                                                          |
|  | <b>Protective conductor terminal</b><br>The inverter has to be firmly grounded to ensure the safety of personnel.                                                                                                        |
|  | <b>Risk of electric shock, Energy storage timed discharge</b><br>Electrical shock danger exists in the capacitor; the cover shall be moved at least 5 minutes later after all powers are disconnected.                   |

# Safety Instructions 2

## 2.1 Notice for use

Inverter installation and service personnel must be trained and familiar with the general safety requirement when working on electrical equipment. Installation and service personnel should also be familiar with the local laws and regulations and safety requirements.

- Read this manual carefully before operation. The equipment will not be under warranty if failing to operate according to this manual.
- Operation on the inverter must be for qualified electrical technician only.
- When inverter operating, don't touch any electrical parts except for the touch-screen.
- All electrical operation must comply with local electrical operation standards.
- Permission from the local utility company is required before installing the energy storage system and only professional personnel are qualified for the operation.

# Product Description 3

## 2.2 Installation

Proper installation requires following all the instructions in the user manual involving transportation, mounting, wiring and commissioning. we do not cover warranty for the inverter damage due to failing to use it properly.

The protection level of the inverter is IP20, which is designed for indoor installation.

Please refer to chapter 5 for installation instruction.

Other notice for using the inverter:

- Pay attention to the safety instructions listed here and below.
- Pay attention to the user manual of energy storage controller.
- Technical data related to equipment shall be considered.

## 2.3 Important note



Item 1: Static electricity can cause damage to the inverter electrostatic discharge may cause unrecoverable damage to inverter internal components!

When operating the inverter, operator must comply with anti-static protection norms!

Item 2: Restriction

The inverter cannot be directly used to connect the life support equipment and medical equipment!

Item 3: Precautions


Make sure installation tools or other unnecessary items are not left inside the inverter before starting up.

Item 4: Maintenance notice


Maintenance can only be carried out after the inverter totally discharged.

## 3.1 Energy Storage System

HPS bidirectional battery inverter is designed for energy storage system, it converts DC current generated by battery bank into AC current and feed it into the load/grid, also it can take power from solar inverter or grid to charge battery to ensure uninterrupted power supply to the load.




## 3.2 Circuit Diagram of the Inverter



## 3.3 The Layout of the Main Components

### 3.3.1 External Components

The main external components of the energy storage controller include: LED indicator, LCD touch screen, off-on knob, emergency stop button and other parts.



Appearance description of energy storage inverter

| NO | Name             | Description                                                                   |
|----|------------------|-------------------------------------------------------------------------------|
| 1  | Power indicator  | When power supply is normal, the indicator displays yellow.                   |
| 2  | FAULT            | When inverter is faulty, the indicator displays red.                          |
| 3  | Touch Screen LCD | Operation information display, receive control command and parameters setting |
| 4  | OFF/ON knob      | Only control the grid-side switch, and does not control the DC-side switch    |
| 5  | EMERGENCY STOP   | Shut down the inverter when pressed down                                      |
| 6  | Dust screen      | Prevent dust from entering into the inverter                                  |

Part description

### ● Indicator

The energy storage controller adopts intelligent design. There are two LED indicators on the inverter which is used to display the current status of the inverter.



| LED   | Description                                                       |
|-------|-------------------------------------------------------------------|
| POWER | The indicator lights when power supply to the inverter is normal. |
| FAULT | The indicator lights when there is failure in circuit system.     |

### ● Emergency STOP

The emergency stop button is only used in case of emergency, such as: serious failure in the grid, fire, etc.



Emergency STOP

The emergency stop button immediately disconnects the inverter from both grid and battery, which ensure the safety of the inverter. By pressing the emergency stop button, the device will be locked in the "off" position. Only release the emergency stop button by rotating it clockwise and closing AC, DC breaker, can the inverter resume working normally.

### ● Off-on knob

It is used to start or stop the inverter.



Off-on knob


Please read Section 8 "operation" for detailed switch on / off process.

### ● Touch screen

It displays the inverter's operating parameters, power generation, and faulty information record. Please refer to Section 7 for details.

### 3.3.2 Internal component

The internal components of the energy storage inverter include: PV circuit breaker, battery circuit breaker, power grid circuit breaker, maintenance switch, load circuit breaker, power supply micro break, AC lightning protection switch, PCB, etc.



The front structural drawing of HPS30

| NO | Name                           | Description                                               |
|----|--------------------------------|-----------------------------------------------------------|
| 1  | PV input                       | Control the connection of battery and HPS                 |
| 2  | Battery input                  | Control the connection of battery and HPS                 |
| 3  | AC input                       | Control the connection of grid and HPS                    |
| 4  | BYPASS                         | Maintenance switch, see 9.1.3 for details                 |
| 5  | AC output                      | Control the connection of load and HPS                    |
| 6  | AC lightning protection switch | Switch for AC lightning protection                        |
| 7  | Interface board                | Inverter power supply conversion PCB                      |
| 8  | Control board                  | Inverter main control board, with communication interface |
| 9  | Sampling board                 | Voltage current temperature sampling PCB                  |
| 10 | Power board                    | System internal power supply PCB                          |
| 11 | N terminals                    | Load and grid N terminals                                 |
| 12 | Earth terminals                | Grounding bronze terminals                                |

### 3.4 Operation Mode and Status

Please refer to Section 7.2.4 for details on operation mode setup procedure.



#### Caution!

Before the machine leaves the factory, the operation mode will be set according to the technical agreement. We will not be responsible for the consequences caused by modifying the operation mode without the consent of us. Please contact personnel for modification if needed.

#### 3.4.1 On Grid Mode

Optional functions in grid connection mode:

Anti-backflow enable

1. When anti-backflow enable is set to 1, feeding power to utility grid is restricted.
2. When anti-backflow enable is set to 0, HPS can feed power to utility grid.

Grid&PV charge together enable

1. When simultaneous charging function enable is set to 1, grid and PV can charge battery simultaneously.
2. When simultaneous charging function enable is set to 0, grid and PV can not charge battery at the same time.

Please refer to Section 7.2.4 for setup procedure.

##### 3.4.1.1 Load first mode (anti-backflow function optional)

1. When PV energy is sufficient, PV supply priority to load, the remaining to battery.
2. When PV power is lower than load power, battery discharge automatically. If battery discharged cutoff voltage or cut-off SOC (depending on battery type), it will stop discharging, PV and grid supply power to the load together. The power supply can be restored when the battery is charged to the set value of battery saturation.

See Chapter 7.2 for details of discharge cut-off voltage, SOC and BAT\_charged\_saturation.

##### 3.4.1.2 Battery first mode (anti-backflow function optional)

1. When the PV energy is sufficient, PV supply priority to battery charge, the remaining to load;
2. When PV energy is insufficient, the PV charge the battery first. The power grid only supplies all loads without charging the battery. It is optional to charge the battery at the same time (PV&grid charge together enable, which is set to 1 by default when leaving factory);
3. If the grid connected backup mode is not discharged or switched to other modes, To maintain electrochemical activity, the battery will enter the discharge state after one week of current limiting charging, and the discharge power will be calculated according to battery specifications.

##### 3.4.1.3 Time shifting mode(anti-backflow function optional)

The period of economic mode is divided into peak period, fair period and valley period. Please refer to section 7.2.4 for the setting details.

1. Valley price: working logic is the same to the backup priority mode's.

2. Fair price:

A. Battery can neither discharge nor be charged by grid.

B. PV power supply priority to load, the remaining to battery when PV power is higher than load.

C. When PV power is lower than load power, PV and grid supply load, PV doesn't charge battery.

3. Peak price:

A. Grid will not charge battery.

B. When PV power is higher than load, PV supplies to load, the remaining to battery.

C. When PV power is lower than load power, there are two conditions:

(1) When battery voltage is higher than the discharge cut-off voltage or the SOC is higher than discharge cut-off SOC (depending on the battery type), PV and battery supply the load.

(2) When battery voltage is less than or equal to the discharge cut-off voltage or the SOC is less than discharge cut-off SOC (depending on the battery type), the battery does not discharge, and the PV and the grid jointly supply the load and do not charge the battery.

##### 3.4.1.4 Peak-shaving(Grid)

**Note:** in this mode, the upper limit power of power grid should be set. This value only limits the power taken from grid, not the power fed to grid.

1. When PV power is greater than the load and charging power, do not take power from the grid, PV supplies load and charge the battery;

2. (When PV power + upper limit power of grid) is greater than (load power + charging power), grid and PV supply load and charge battery at the same time.

3. When (PV power + upper limit power of power grid) is greater than the load power, grid and PV supply priority to the load and the remaining charge batteries.

4. When (PV power + grid upper limit power) is less than the load power, the grid, PV and battery supply the load at the same time.

### 3.4.1.5 EMS MODE

#### Description:

1. In EMS mode, the inverter is controlled by the remote EMS management system, doesn't have its own operation logic, and power is controlled by EMS command.
2. In EMS mode, there is no charging curve, only over and under voltage protection value.
3. The power under control includes PV power and DC-AC rectifier power (when not connected to grid, only PV power can be controlled, and inverter power can be adjusted automatically according to load). When it is set to inverter, DC output to AC. when it is set to rectifier, AC will charge the battery.
4. EMS mode does not support manual operation, only remote EMS sending instructions.
5. Please refer to RS485 command instruction in Capture 10.5.

#### Control Description:

| No. | Diagram                                                                | Description                                                                                                      |
|-----|------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|
| 1   | <p>All PV power charge to battery, DC-AC rectifier power remains 0</p> | Keep the DC-AC rectifier power at 0, only modify PV power, at this time, PV is fully charged and AC has no power |
| 2   | <p>PV power remains 0, all the DC-AC power send to AC</p>              | Keep PV power at 0, only modify the DC-AC power, at this time, the battery inverts to AC                         |

| No. | Diagram                                                          | Description                                                                                                                           |
|-----|------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|
| 3   | <p>PV power remains 0, all rectifier power charge to battery</p> | Keep PV power at 0, and only modify the rectifier power. At this time, the AC charge battery                                          |
| 4   | <p>PV power ≥ DC-AC power</p>                                    | PV power higher than or equal to inverter power, PV convert to AC in priority, remaining charge to battery                            |
| 5   | <p>PV power &lt; DC-AC power</p>                                 | PV power lower than DC-AC power, PV and battery output to AC together                                                                 |
| 6   | <p>PV power + rectify power charge to battery</p>                | PV and AC power charge battery together, when PV+AC power exceeds the max. charging value, use PV power to charge battery in priority |



### 3.4.2 Off-grid mode

1. When PV power is higher than load power, PV supply priority to load power, the remaining to the battery charge.

2. Battery discharge automatically when PV power is lower than load power. When the battery is discharged to the undervoltage alarm point or minimum SOC (depending on battery type), there are two situations:

a) By default, continue to discharge to the battery undervoltage alarm point, then turn into PV charging mode, in the meantime there is no AC output.

b) If the DG access function is enabled, the inverter sends a relay signal to start the DG, which supplies the load or charges the battery.

### 3.4.3 Generator mode

I. Generator access function (dry contact control)

In the off grid mode, when the battery is discharged to the under voltage alarm point, HPS sends a relay signal to start the DG and enter DG mode. The generator will supply power to load; at the same time, HPS stops supplying power to the load and only charges the battery.

1. When PV power is greater than the charging power, PV power is only used to charge the battery; the DG only supplies the load.

2. When PV power is less than the charging power, PV supplies priority to battery; DG supplies power to the load and optionally charges the battery.

3. When the battery is charged to "SOC upper limit" or "floating charge current limiting point" (depending on the battery type), the inverter sends a signal to stop the DG and switch to off grid mode.

4. When there is no power grid, the DG can be directly connected to the power grid end of the inverter; when there is power grid and DG neither, it needs to be used with ATS.

See Chapter 7.2.4 for details of setting SOC upper limit and floating charge current limiting point.

### 3.4.4 PV mode

1. When utility is unavailable, turn on the knob without clicking the LCD power-on key, HPS will start to enter PV mode, then PV only charges the battery and will not invert AC output.

2. When utility is unavailable, manually start the LCD screen in PV mode, then inverter enters off grid mode.

3. In the off grid mode when discharged to the battery low voltage alarm point, inverter will stop DC/AC converting and automatically switch to PV mode. When battery is charged to the set voltage (single PV to off-grid), it automatically switches to off grid mode.

4. When the power grid returns normal, inverter automatically switch to grid tie mode.

See Chapter 7.2.4 for details on charge change to offline.

### 3.4.5 Automatic on/off grid switch

Operate logic: when the power grid is normal, cut the grid automatically, otherwise when the power grid is abnormal, cut off the grid automatically.

### 3.4.6 Fault mode

When the inverter fails, the contactor on AC and DC sides will immediately disconnect and shut down the inverter, so as to ensure the system safety. At this time, the inverter will continuously monitor whether the fault is eliminated, if not, it will maintain the fault state; after eliminated, it will restart automatically.

### 3.4.7 Permanent failure mode

When the inverter has a serious fault, the contactor on AC and DC sides will immediately disconnect and enter a permanent fault state to ensure safety of the system. When permanent fault is detected three times in a row, all switches will be disconnected. For example, the IGBT module of the inverter is faulty. When inverter enters this permanent failure mode, please do not repair it without permission. You should contact the personnel of the local dealer or call us for help.



When temperature gets too high, output power of the inverter will decrease, which is normal. However, if this happens frequently, check the cooling surface of the inverter or place it in a place with good ventilation condition. If the fan gets dirty, please clean the dust on it. If there is any problem inside the inverter, please contact the professional service department for help.

## 3.5 Function protection

Anti-islanding protection

When the local power grid is shut down due to fault or equipment maintenance, the HPS will physically cut off the connection with grid in order to protect the operators working on the power grid, the HPS fully meets the relevant national standards.

Lightning protection

The HPS has built-in lightning protection module, with DC / AC over-voltage lightning protection, to avoid being struck by lightning.

For more protection functions, please refer to Section 7.3.

## 3.6 Dimension

| Model               | HPS30          |
|---------------------|----------------|
| Dimension (W*H*Dmm) | 950/1860/750mm |
| Weight(KG)          | 440            |

Figure--Dimension and weight of HPS

## 3.7 Packing information

| NO | Name                | Unit | Qty. | Note         |
|----|---------------------|------|------|--------------|
| 1  | HPS                 | unit | 1    | Key included |
| 2  | User manual         | pcs  | 1    |              |
| 3  | Certificate         | pcs  | 1    |              |
| 4  | Factory test report | pcs  | 1    |              |

Figure--Packing information

# Transportation and Storage 4

## 4.1 Transportation

Transportation should follow the transportation methods described in the user manual. The inverter's weight and center of gravity should be taken into account during transportation. The center of gravity is marked on the box.



### Caution, risk of danger

During transportation, lifting equipment and personnel must be qualified. The inverter should be placed vertically and the inclination cannot be more than 10 degrees. It is not allowed to place the inverter upside down or transport in a horizontal position. Incorrect lifting and transportation can lead to serious injury, property loss and damage to the inverter.

## 4.2 Inspection and storage

The inverter should be carefully checked before signing the document from the transportation company. Check the received items against delivery note, and if there is any defect or damage, immediately notify the transportation company. If necessary, you can seek help from our Customer Service department.



### Caution!

HPS30 can only be stored when it is stopped and all the doors are closed in a dry room to protect the internal circuits against dust and moisture.

# 5 Installation

## 5.1 Installation condition requirements

To ensure normal operation of the machine, the installation environment is required as follows:

- > The ingress protection of inverter is IP20. Moreover, as this product is an electronic equipment, it shall not be placed in humid environment;
- > Install indoors and avoid sunlight and rain;
- > Ventilation of the room shall be good;
- > The installation environment shall be clean;
- > As some noise will be produced in operation, this equipment shall be installed far from residential quarters;
- > The installation ground shall be even enough, and firm enough to support the weight of inverter;
- > The installation position shall be convenient for maintenance;
- > Ambient temperature range:  $-25^{\circ}\text{C}\sim 55^{\circ}\text{C}$ ;
- > Appropriate space shall be reserved for the machine to ensure ventilation and cooling.

We suggest inverter is installed in the distribution room. The floor, wall clearance, Ventilation equipment and precaution should be designed by professional personnel and satisfy the following requirements.

### ● Foundation requirement

Inverter is required to install on even ground with fire-retardant material as the surface or channel steel support structure, and sag or tilt ground is prohibited. The foundation shall be solid, safe and reliable. The foundation shall be capable of bearing the load of the inverter. Its load bearing ability shall be concerned throughout the installation place selection.

### ● Clearance space


During installation of the inverter, appropriate space shall be left to the wall or other equipment, in order to satisfy the requirements on narrowest maintenance channel, emergency access and ventilation.



In front of the installation place of inverter, a space of 0.8m or more shall be ensured, the back 0.8m or more, the top 0.8m or more to ensure easy installation, cooling and maintenance.

### ● Cable trench

The cable connection of inverter adopts bottom inlet and bottom outlet. Cable trenches are recommended to ensure easy installation and maintenance.



The cable trenches are often designed and constructed by the construction side based on relevant standards, with the equipment weight and dimensions required to be considered. Good electrical connection is needed between different cable trenches and GND terminals.

### ● Wiring specification

Cables in the inverter can be classified into either power cables or data cables. In cabling, the power cable shall be kept far away from, and the cable shall be kept in right angle at cross. The cable shall be as short as possible, and an appropriate distance shall be kept to the power cable. It is recommended that the insulation impedance of BT + and BT - at DC end to ground to be higher than  $1\text{m}\Omega$

The power cable and data access shall be placed in different cable trenches respectively to avoid lengthy routing between the power cable and other cables, so as to reduce the electromagnetic interruption caused by sudden change of the output voltage. The distance among the power cable and data access shall be more than 0.2m. When the cables are crossed, the cross angle shall be 90 degrees, while the distance can be reduced appropriately.

● **Ventilation requirement**

In operation, inverter will produce a lot of heat. When ambient temperature is too high, the electrical property of the equipment may be affected, the equipment may even be damaged. Therefore, the heat release shall be fully considered in designing the control room to ensure operation of the equipment in high efficiency.

● **Ventilation environment**

To satisfy the ventilation requirement of inverter, its installation environment shall meet the following conditions:

- ※ Inverter shall be prevented from being installed in the place of poor ventilation condition and insufficient air flow;
- ※ The air inlet shall have enough air supplementation.

● **Ventilation equipment**

To ensure safe and reliable operation of the equipment, the ambient temperature must be within the permission range -25°C~ 55°C, therefore, appropriate ventilation devices must be equipped with to release the heat generated by the equipment.

1. There must be ventilation equipment inside the distribution room to ensure release of the waste heat generated by the inverter from the equipment, and allow for maximum ambient environment temperature. This can be realized from installation of exhaust devices.
2. Another fan can be added at the air duct outlet to exhaust the air out and ensure balanced pressure.
3. The direction of the air outlet shall be selected according to the local actual wind direction.
4. Pay attention to the dustproof measures and waterproof design at the air inlet and outlet.
5. If more air ducts are required, its dimensions shall be designed by the professionals according to the air output amount.

**Other protections**

With IP20 of protection level, inverter is appropriate to be installed in dry and clean environment. Meanwhile, water leakage of the house shall be prevented, as it may damage the inverter. According to EMC requirement and noise level, the inverter shall be installed in industrial environment.

## 5.2 Tools and spare parts required for whole machine installation

Tools and spare parts required for installation is as follows:

- Hoisting crane, forklift or fork lift truck (with the capacity for bearing the weight of the inverter)
- Torque wrench
- Screwdriver
- Wire stripper
- Terminal crimping machine
- Heat dryer
- Megger and multimeter

## 5.3 Mechanical Installation

### 5.3.1 Transportation of packaged whole machine

This inverter is transported as an integrated unit, and the user can hoist it from the bottom with a forklift, or move it with a hoisting crane or crane.

**Note 1:** The inverter is integrated and cannot be dissembled either in transportation or installation. Any fault attributed to modification unauthorized by the us is beyond the quality assurance.

**Note 2:** In movement, tilt, violent shake or sudden force upon the inverter shall be prevented, such as sudden down of lifting.

**Note 3:** Please read carefully the labeled parameters to select an appropriate transportation means and storage place.

We suggest the user make use of forklift to move the inverter if possible.

**We suggest the user make use of forklift to move the inverter if possible.**



Before the inverter is moved to the designated place, we suggest to lay the DC input cable and AC main power supply cable. As these cables are relatively thick, they are hard to be cabled after the inverter is installed.

To keep the equipment in a better protective status, please adopt transportation with package as much as possible, and comply with the labels printed on the package in transportation:

| Sign | Indication                                                                                                 |
|------|------------------------------------------------------------------------------------------------------------|
|      | The gravity centre                                                                                         |
|      | Lifting logo                                                                                               |
|      | Face up to prohibit the inverter horizontally, tilted or upside down                                       |
|      | Handle with care, to avoid the transport environment too intense collision friction damage to the inverter |
|      | Keep away from moisture                                                                                    |

Inverters whose packages are not demolished can be moved with forklift, hoisting crane or crane. In moving, attention shall be paid to the weight painted on the package to ensure enough load capacity of the devices. As the gravity center of the equipment locates at the lower place symmetrical in front and back and left and right, the support point or hoisting point shall be arranged reasonably in transportation.

The forklift transportation is the standard one. The gravity center of the cabinet in transportation should locate between two forks of the forklift. The big-size inverter may block driver's sight, and it shall be treated with cooperation of the aid personnel.

### 5.3.2 Movement and installation of bare machine

#### ● Demolish the package of inverter

Please demolish the packaged cabinet of the equipment according to the following procedures:

Procedure 1: Demolish the wood side and roof of the packaged cabinet

Procedure 2: Demolish the out-set package material on the machine


Procedure 3: Demolish the fastening screws between the machine and the pallet

- ① Demolish the front and back cover lids of the pedestal
- ② Screw off the hold-down nuts at the bottom of the wood pallet
- ③ Remove the screws, and the inverter will depart from the wood pallet.

#### ● Movement and installation of bare machine

The inverter with demolished package can be moved with forklift, hoisting crane, slide rail or crane. If the package demolished place is far from the final installation place, it can be transported with forklift containing wood pallet.

If the wooden pallet at the bottom of the machine has been removed, when using the forklift, the front and rear cover plates of the base need to be removed first, and the center of gravity should be placed in the middle of the two forklifts, and then start lifting and transporting, as shown in the following figure:



#### Caution, risk of danger

We must act slowly and gently when transporting the inverter with forklift to avoid violent vibration of the inverter or collision with other objects.

If lifting method is used for moving, please pay attention to the lifting position, ensure that the lifting angle is 70°, and be cautious of the center of gravity position of the inverter.

#### NOTE:

- It is necessary to always pay attention to the position of the center of gravity of inverter.
- Take necessary auxiliary measures to ensure the safety of transportation personnel
- Take necessary auxiliary measures to ensure that the equipment is delivered to the final installation site.

## 5.4 Electrical installation

### 5.4.1 Input and output requirements



#### Caution, risk of danger

- There is a danger of electrical shock of high voltage in inverter's operation; only electricians of professional skills can operate.
  - All connections with this equipment shall be done under non-voltage state.
  - The inverter may be damaged if input or output terminal is incorrectly plugged.
- Failure of acting upon this information may cause serious personnel injury or significant property loss even to death.

#### ● Battery

The battery operating voltage is 352V-600V. The battery voltage should be not lower than 352V and not higher than 600V.

#### ● PV module

The maximum MPPT working voltage of PV module should not be more than 820v and the open circuit voltage should not exceed 1000V, otherwise the equipment will be in over-voltage protection state and cannot work normally. The MPPT voltage range of should be within 480v-800v, which means the minimum PV working voltage shall not be lower than 480v. And under the rated power, maximum working voltage shall not be higher than 800V.

#### ● PV and battery configuration

The MPPT voltage shall be greater than the maximum voltage of the battery, otherwise, the battery cannot be fully charged by PV power. However, it is suggested that the voltage difference not be too large, or it will speed up the machine wearing and the reduce efficiency. The best configuration is that the voltage of MPPT is 100V higher than the maximum battery voltage.

#### ● Three phase grid connection

The inverter will constantly detect whether the grid meets the grid connection conditions constantly. The following are the grid restrictions according to golden sun (China) (the grid connection requirements would vary from countries, and the protection parameters of the inverter can be set referring to the local grid connection regulations). The grid is three-phase. At the same time, the permission of the local power department shall be obtained before installing the grid connected system.

| Model                | HPS30     |
|----------------------|-----------|
| Grid voltage limit   | 360V-440V |
| Grid frequency limit | 55Hz-65Hz |

#### ● Cable requirements

1. Please select the corresponding withstand voltage cable according to the voltage level.
2. Because different voltage will lead to change of current, please calculate the corresponding cable diameter according to the actual voltage range. The following table only provides the cable requirements of the lowest working voltage and rated power. In actual application, it should be calculated according to the actual voltage, please inquire the after-sales staff of us if you need more details.

| Cable              | Cable Diameter Requirements (mm <sup>2</sup> ) Max. total diameter | Aperture |
|--------------------|--------------------------------------------------------------------|----------|
| Model              | HPS30                                                              |          |
| PV                 | 35mm <sup>2</sup>                                                  | Φ8       |
| Battery            | 35mm <sup>2</sup>                                                  | Φ8       |
| Utility            | 35mm <sup>2</sup>                                                  | Φ8       |
| Load               | 16mm <sup>2</sup>                                                  | Φ6       |
| N wire             | 35mm <sup>2</sup>                                                  | Φ8       |
| Earth wire         | More than 16 mm <sup>2</sup> . Green and yellow is recommended     | Φ8       |
| Communication Wire | 0.75mm <sup>2</sup> , shielded communication line is recommended   | /        |

#### 5.4.2 DC side wiring



##### Caution, risk of danger

The positive and negative of the battery shall not be connected in reverse. A multimeter shall be used to determine the polarity first, and then connect into the corresponding input ends of the battery.

Specific procedures are as follows:

- 1) Cut off the distribution circuit breaker at the DC side, and ensure that no voltage on the wire at DC side.
- 2) Use a multimeter to measure the open circuit voltage of the battery to ensure that it is within the allowed range.
- 3) Determine the positive and negative pole of the battery with a multimeter.
- 4) Strip off the insulation skin at the end of the cable.
- 5) Crimp the wiring copper nose.
  1. Put the stripped copper core into the crimping hole of the copper nose.
  2. Use the terminal pressing machine to press the copper nose tightly. The number of crimping shall be more than two.
  - 6) install the shrink fit sleeve.
    1. Select the heat shrinkable sleeve which is more consistent with the cable size, length is about 5cm.
    2. The heat shrinkable sleeve shall be sleeved on the copper nose of the wiring to completely cover the wire pressing hole of the copper nose.
    3. Use a heat blower to tighten the heat shrink sleeve.
  - 7)Connect the positive of the battery to the "Battery-input +" of DC input
    1. Select the bolts that match the copper nose.
    2. Connect the copper nose at both ends of the wiring firmly to the "battery input +" end of the inverter and the positive pole of the battery.
    3. Tighten the bolts with a screwdriver or wrench.
  - 8)Connect the "battery input -" end of the inverter to the negative pole of the battery by cable according to the method of step 7.
  - 9)Cable the "PV input +" end of the inverter to the positive pole of the PV module according to step 7.
  - 10)Cable the "PV input -" end of the inverter to the negative pole of the PV module according to step 7.
  - 11) Please be sure that all wirings are fastened.

#### 5.4.3 AC side wiring



##### Caution, risk of danger

When connecting the AC grid, cut off the circuit breaker at the AC side to ensure that the AC wire connecting to terminals has no electricity.

The output voltage of the AC side of the inverter is 400V, which is connected to the power grid through a transformer. The wiring method of AC side and grid side is as follows:

- 1) Cut off the circuit breaker at AC side, to ensure that the AC wire connecting to terminals has no electricity. Confirm it with a multimeter.
- 2) Ensure that the wiring phase sequence at AC side is consistent with the phase sequence at grid side.
- 3) Strip the insulation skin off at the end of the cable
- 4) Crimping copper nose
  1. Put the exposed copper core of the stripped wire head into the crimping hole of the copper nose.
  2. Use the terminal crimper to compress the copper nose of the wiring, and the number of crimping shall be more than two.
- 5) Install the shrink fit sleeve.
  1. Select the heat shrinkable sleeve which is more consistent with the cable size, length is about 5cm.
  2. The heat shrinkable sleeve shall be sleeved on the copper nose of the wiring to completely cover the wire pressing hole of the copper nose.
  3. Use a heat blower to tighten the heat shrink sleeve.
- 6) Connect "L1" cable to "L1" of AC distribution cabinet, i.e. phase A (U). Select the bolts that match the copper nose.
- 7) Connect "L2" of AC output to "L2" of AC distribution cabinet, i.e. phase B (V); connect "L3" of AC output to "L3" of AC distribution cabinet, i.e. phase C (W); connect n-line to n wire on the inverter.

#### 5.4.4 Earthing

Inverter must be earthing well for safety; Please make sure of the connection between PE in power distribution cabinet and PE copper in the inverter good; and make sure the earthing cable more than half of load cable, and earthing resistance is not lower than 4Ω.

All wiring into the channel at the bottom of the inverter to be all the wiring is completed, the connection port must be sealed with dust cotton, to prevent dust from entering the inside of the inverter.




Connect several connecting wires on the PE copper bar as some parts inside the energy storage controller need to be grounded, please do not change them without permission, so as to avoid electric shock

## 5.5 Communication

HPS series energy storage controller adopts a variety of communication modes. The following figure is the schematic diagram of the control board interface.


Note: there are different versions of the control board. Please look for the communication interface according to the actual control board.



### 1. RS485 communication

The inverters communicates with each other through RS485 line, and finally connects to our Shinemaster, which uploads the inverter data to the server through network. It can remotely and real-time monitor the operation status of single / multiple inverter(s). Terminal blocks are used at both ends of RS485 communication line, by paralleling the two blocks it will make RS485 line, which shall not exceed 1000m. In order to ensure transmission quality, special shielded communication line shall be applied. The 485 interface is located in the internal control board, please distinguish "A" and "B".

If Shinemaster is not used for monitoring, the user's own monitoring equipment needs to be compatible with 485 communication protocol of us.



### 2. BMS-CAN communication

- CAN communication is required when inverter is equipped with battery with BMS. Connect CAN A of inverter to the CAN port of battery, and communication can be realized after docking the communication protocol.

- Terminal blocks are used at both ends of communication line, by paralleling the two blocks it will make a CAN line. Special shielded communication line is recommended

- The CAN A interface is located in the internal control panel. Please distinguish "L" and "H".

- If the user does not use the BMS battery system produced by us, the user's own system needs to be compatible with the BMS communication protocol of ours.

### 3. ATS-CAN communication

- When the inverter is used with ATS, it needs to communicate with ATS. The inverter CAN-B is connected to the CAN interface of ATS. Note: only ATS produced by us can communicate with the inverter.

- ATS produced by us has its own special communication line for communication with inverter.

- The CAN-B interface of the inverter is located in the internal control panel of the machine. Please distinguish "L" and "H".

### 3. Parallel communication (special for customized parallel function)

- Parallel communication is required when two same HPS models are used in parallel.

- DB9 communication line is used for parallel communication, which goes with the shipment in parallel scheme, also there will be special parallel communication interface.

- When paralleling two HPS models, DB9 communication line is used to connect the parallel interfaces of two models. One of the two parallel interfaces on the control board can be selected as the reserved interface.




As Parallel function is a special customized function, please use it under the guidance of our staff.


## 5.6 ATS wiring

When the system needs to be connected to utility grid and generator at the same time, an ATS is required to be used together with HPS, which is mainly used to switch between the utility and generator.

2. The main wiring of ATS and HPS is ATS internal panel power line, CAN communication line and AC power line. Wiring diagram is shown as below:




3. There are three circuit breakers in ATS. The middle circuit breaker is connected to the power grid switch (AC input) of HPS. The other two are grid switch (grid) and generator (Gen) switch. Pay attention to the printing on cabinet. It is not allowed to connect incorrectly, neither is it for the three phase sequence, otherwise the system cannot operate normally.



4. ATS needs to communicate with HPS, which is connected on CAN-B of HPS. Pay attention to the sequence and distinguish "L" and "H".


5. ATS needs to be powered by HPS and connected to the wiring hole at the upper end of the battery air switch of HPS. Pay attention to positive and negative, red is positive and black is negative.



When the ATS of other manufacturers are applied CAN communication mode cannot be used to distinguish the generator and power grid. They can be distinguished by connecting passive dry contact signal (it is suggested that the switchover time for ATS to switch between generator and grid should be more than 5 seconds to ensure the correct mode switching of the inverter). Connect the signal line to the CN14 port of the energy storage inverter's interface board. It's default that open signal means connecting the power grid, and close signal means connecting to generator.

### 5.7 Diesel generator dry contact wiring

The inverter has a passive dry contact contactor to control the diesel generator, and the following is the dry contact structure diagram (initial state).



### Wiring instructions:

- "13" and "14" are the power supply of dry contact contactor, no need for wiring.
- There are two groups of connection contacts in the dry contact, "1", "5" and "9" are a group, "4", "8" and "12" are a group, and the two groups will act at the same time.
- The initial state is that when the inverter does not send the command to start the diesel generator, the state between "1" and "9" means stay closed, and the state between "5" and "9" means stay opened. When the inverter sends the command to start the diesel generator, "1" and "9" are switched to stay opened from stayed closed, and "5" and "9" are switched to stay closed from stayed opened. "4", "8" and "12" are the same.
- When the current needs to pass through the dry contact, the AC voltage shall not exceed 240V, the DC voltage shall not exceed 28V, and the current shall not exceed 5A.

### 5.8 Parallel wiring


#### ● Parallel operation system:


- Two same HPS models are used in parallel, output and supply load at the same time operating in the same mode.
- Parallel operation means in off-grid parallel mode, multiple energy storage controllers maintain the same AC frequency, amplitude and phase.

#### ● System requirements:

- It must be the same HPS model.
- The program has to be customized parallel program, default single model running programs is not applicable in parallel case.
- At present, it supports at most two HPS in parallel.

#### ● System wiring diagram shown as follow:





## ● Wiring instructions:

1. Pay attention to the same photovoltaic configuration of each equipment.
2. In order to reduce the circulation loss, it is recommended to share the battery. When it is a lithium battery with BMS, both computers need to communicate with BMS.
3. The two HPS supply load together, The load terminals of the two paralleled units are connected before connecting to load, and the length from combination point of the two HPS to the load terminals must be the same.
4. The two HPS share the utility grid or generator. When require to switch between these two power source, it shall be used with ATS. The installation method is the same as that of single unit installation.
5. The parallel system has special parallel communication port and communication line, which connects the two parallel machines.
6. In order to ensure the communication quality, please install the paralleled inverters at the same location to reduce the communication distance. The complimentary line of parallel communication is only 5 meters long, the paralleled inverters distance should be within 3 meters.

## ● Operation mode:

The working mode of the parallel system is the same as that of the stand-alone system, but the working mode of each device should be set to the same.

Parallel redundant function can be selected for parallel system. It needs to set the number of parallel units and redundant number.

Number of parallel units: the total number of equipment in parallel operation system. Redundant number: the maximum number of faults in parallel system, which can only be set to 0 or 1. When it is set to 0, when any equipment of the parallel system fails, all the equipment will turn to failure mode; when set to 1, if the number of faults is less than 1, other devices still maintain normal operation (the maximum number of supported faults is 1). Redundant function selection Description: Redundancy can only be selected when one equipment fails and other equipment can still drive all loads; otherwise, it will cause overload of equipment.

Parallel redundant function selection: this function can only be selected when one equipment fails and other equipment can still drive all loads; otherwise, it will cause overload for the equipment.

## 6.1 Inspection before operation

Before the inverter is put into operation, its installation shall be inspected. At least two staff do the inspection according to the items listed below to ensure the correctness of the installation.

### Inspection items for installation

- There is no deformation or damage to the inverter.
- Bottom of the inverter is fixed securely, the foundation support is stable and reliable.
- There is enough space around the inverter.
- The temperature, humidity and ventilation conditions of the environment where the inverter is located meet the requirements.
- There is enough cooling air for ventilation.
- Cabinet sealing protection is complete and reliable

### Electrical inspection

- Inverter is grounded completely and firmly.
- The grid voltage matches the rated output voltage of the inverter.
- The phase sequence of grid connection is correct, and the tightening torque meets the requirements.
- The positive and negative poles of DC input connection are correct, and the tightening torque meets the requirements.
- Communication wiring shall be correct and keep a certain distance from other cables.
- Cable number is marked correctly and clearly.
- The insulation protection cover is complete and reliable, and the danger warning label is clear and firm.

### Other inspection

- All useless conductive parts shall be tied with insulating ties.
- There are no tools, parts, conductive dust or other foreign matters left inside the cabinet.
- There is no condensation of moisture or ice in the cabinet.



## 6.2 Power on steps

Energy storage controller adopts the integrated AC and DC power supply method, and LCD can be lit when there is AC or DC alone.

- **Battery power supply**

The battery can be used for the first time power-on. When the battery breaker is closed, the LCD should be on.

- **AC power supply**

AC power supply can be used for the first time power-on. Turn on AC input switch, bypass switch, AC output switch and the micro breaks, LCD should be on. When the energy storage controller is powered by AC, as long as the battery voltage is detected to be abnormal for more than 10 minutes, all circuit breakers except bypass will be switched off, and inverter won't be able to start and operate when powered by AC source alone. After LCD is lighted by AC power supply, the bypass switch must be off before the machine turns on.

It is recommended to use batteries to light up the screen. After power on, please do not switch the power-on knob immediately. Please check the historical information page and check whether the operation setting is in line with the actual situation. Please refer to Chapter 7 for details.

After powering on the LCD, it will enter the home page after about 15s. Then you can begin to read the information and set the parameters.

Inverter communication state (√ means normal and × means communication fault), station number and system time is displayed at the right top of each page of the LCD.

Each page has five commonly used function keys: "run data" "historical information" "system settings" "Power on/off" "Home" at the below of the page. Through these keys users can easily operate. On the left of the page it shows the corresponding sub-menu of the five keys, and it will be marked green after selected. A

## 7.2 LCD operation

### 7.2.1 Home page


When powered or clicking "Home" button in any interface will enter into the Home page.

This page includes: system operating status, battery power and grid power etc. can be viewed in the page. Pressing the following key can switch to other pages.

# 7 GUI instruction

## 7.1 LCD display screen introduction

User can view the information of the inverter operation on the LCD touch screen, as well as setting the operating parameters. In order to facilitate the operation, a menu is provided below.



HPS LCD Menu logical structure



| Operation status     | Description                                    |
|----------------------|------------------------------------------------|
| Error                | Not started or failed to start                 |
| Wait                 | Start initialization                           |
| Check                | System self checking                           |
| Permanent fault      | Serious failure occurred                       |
| Off grid mode        | Off grid mode with load                        |
| On grid mode         | Successfully connected to grid                 |
| PV mode              | PV only charging mode                          |
| Parallel to off-grid | Parallel system waiting to enter off-grid mode |
| Parallel to on-grid  | Parallel system waiting to enter on-grid mode  |

**Communication station number:** the number represents the current station number, which is 485 communication station number.

**Grid connected mode:** when the operation state of the inverter is grid connected, the current grid connection mode will be displayed: load priority, battery priority, economic mode, peak shifting, EMS mode and diesel generator mode.

**BMS status:** when it works with lithium battery with BMS, the current BMS status is displayed here. "Wait" is displayed when there is no BMS communication.

### 7.2.2 ON/OFF interface


Clicking "ON/OFF" button in any interface will enter into this interface.

There are "ON" and "OFF" button which is used to turn on and turn off the inverter.

Start up: turn the start knob to on and click "on" to start up successfully.

Shut down: shut down by clicking "off", or turn the start / stop knob to off directly.

If the machine will be turned off for a long time, use the off-on knob to shut it down.




### 7.2.3 Operation data

Click [operation data] at the bottom of any other interface to enter the submenu of "operation data".

The submenu includes: operation data, charge and discharge capacity.

**Operation data:** display the current parameters and real-time data of energy storage power generation, including grid voltage, grid frequency, grid current, DC input voltage, DC input current, temperature in the case and total generation time (real-time update).




## 7.2.4 System setting


Clicking "System setting" button in any interface will enter into this interface.

**Sub menu:** language settings, time settings, inverter information, maintenance. Pressing the left button can enter into the corresponding submenu interface. The default one is language setting interface.

**Language Settings:** Select language, currently it only supports Chinese, English.



**Time settings:** system time setting (if the date and time displayed on LCD is not inconsistent with the actual date and time, they can be modified here).




**Device Information:** This page shows the manufacturer, inverter serial number, hardware and software version information, and the date of manufacturing.



**Maintenance:** the interface requires a password to login. It is for electrician and maintenance personnel who are fully familiar with the structure and working principle of the DC grid system only, in order to avoid damage to personal safety and the inverter.

- Enter the correct password to enter the submenu of "equipment maintenance". The submenu includes: protection parameters, control instructions, power grid management, factory settings. The default one is "protection parameters".
- Parameter modification method: modify the set value. Click Save to change the current value to the same value as the set value. There are several reasons why the current value cannot be changed to the set value:
  - LCD response is slow, you can switch pages to speed up the update.
  - The value exceeds the limit and cannot be saved.
  - Other data on this page has errors and cannot be saved.

## 1. Protection parameters:



**Grid voltage upper limit:** If it exceeds Max. power grid voltage, it will switch to off grid mode. The default setting is 110% of rated voltage.

**Grid voltage lower limit:** If it gets lower than Min. power grid voltage, it will switch to off grid mode. The default setting is 90% of rated voltage.

**Grid frequency upper limit:** If it exceeds Max. power grid frequency, it will switch to off grid mode. The default setting is rated + 2.

**Grid frequency lower limit:** If it gets lower than Min. power grid frequency, it will switch to off grid mode. The default setting is rated -2.

**Check time:** startup detection time, default 60 seconds, minimum 10 seconds, maximum 300 seconds.


**Output power limit:** AC output power percentage. It can be set to 1% - 120%, the default setting is 100%, and it is recommended not to exceed 110%.

**Output voltage setting:** the off-grid output voltage can be set to 380 or 400, and can be changed according to the actual needs. After the change, power off and restart to take effect.

**Output frequency setting:** the AC output frequency can be set to 50 or 60, and can be changed according to the actual needs. After the change, power off and restart to take effect.

**Battery charging current:** can modify the battery charging current. It is recommended not to exceed the protection value of the charging current. Please set according to the actual parameters of the battery to avoid heavy losses caused by overcharge to battery.

**Grid power upper limit:** Only takes effect under peak-shaving mode. It is the upper limit of power taken by the power grid, and the default maximum is twice the rated power.



**SOC up limit/SOC down limit:** only valid in diesel generator mode and when the battery has BMS. When off grid and the current SOC is lower than the Min. SOC, the inverter sends the diesel generator starting command; in diesel generator mode, the current SOC is higher than the upper SOC limit, and the inverter sends the diesel generator closing command.

**Battery charge saturation:** only valid in the on-grid load priority mode, when the battery switches to charging from discharging due to undervoltage, discharging will resume only when the battery unit voltage reaches set value.

$$\text{Recovery discharge unit voltage} = \text{floating charge unit voltage} - \frac{\text{battery saturation set value}}{10}$$

**Floating charge current limit:** set current limiting charging, when the current unit voltage is greater than (floating cell voltage - floating charge current limiting point), enter the current limiting charging state.

$$\text{Target charging current} = \frac{\text{floating cell voltage} - \text{current unit voltage}}{\text{floating charge current limiting point value}} * \frac{\text{battery charging current}}{\text{set value}}$$


**Single PV to off-grid:** in single PV mode, when the cell voltage reaches the set value, it will automatically switch to off-grid mode

**Discharge cut-off voltage:** When the unit battery voltage reaches the discharge cut-off voltage, the battery stops discharging(in off-grid mode start te generator or keep discharging till undervoltage and turns into single PV mode).

**Number of battery packs:** the number of battery in parallel. E.g. 2V / 200ah battery, 240 in series and 2 in parallel, the number of groups should be 2.

**Number of battery cells:** the number of batteries in each string. E.g. 2V / 200ah battery, 240 in series and 2 in parallel, the number in each string should be 240.

**Battery capacity:** single unit battery capacity, unit: ah. If 2V / 200ah, 240 in series and 2 in parallel, the capacity is 200ah.



This page is the battery parameter setting page. As battery is an important part of the energy storage system, the battery parameters need to be carefully confirmed whether they are consistent with the actual situation.

**Batt-charging overcurr protection:** Protection value of total charging current of battery.

**Batt-discharging overcurr protection:** Protection value of total discharge current of battery.

**Floating charge voltage setting:** the floating charge cell voltage of the battery. When the cell voltage reaches this set value, the charging current approaches 0A.

**Battery low voltage warning:** the cell voltage value when battery undervoltage alarm activates.


**Battery low voltage protection:** the cell voltage value of battery undervoltage protection. When the battery voltage reaches this set value due to discharge, energy storage controller will stop for protection.

**Battery over voltage protection:** battery cell voltage to activate the over-voltage protection. When the battery voltage reaches this set value, energy storage controller will shut down to protect.

**Grid power compensation:** forcibly reduce the power taken from grid to maximum of 10kW.

**DG power upper limit:** only takes effect under diesel generator mode, which is the upper limit of generator power. The default maximum setting is twice the rated power(maximum for HPS150 is 240).

**Discharge cutoff SOC:** when the battery is a lithium battery with BMS, the actual SOC is lower than the set value, and the inverter will stop the battery discharge (only valid in on-grid mode). In grid connected mode, it has the same function as "discharge cut-off voltage". When the battery has no BMS, it will not take effect. When the battery has BMS, along with the condition "discharge cutoff voltage", the one which is fulfilled first will take effect.



**Generator Charge Power Up Limit:** The maximum charging power of the diesel generator to the battery can limit the charging power of the diesel generator to the battery.

**Recover Discharge SOC:** When the battery is a battery with BMS, the discharge cutoff SOC is triggered to stop the discharge, and the discharge can continue only when the SOC returns to the set value, and only the grid-connected state takes effect. This does not take effect when the battery does not have BMS. When the battery does not have BMS, the discharge saturation is used to determine the value.

**Charge Stop SOC:** When the battery is a battery with BMS, SOC stops charging when it reaches the set value, and does not take effect when the battery has no BMS. This setting takes effect at the same time as the floating charge voltage, whichever is reached first.

**ATS Communication Station Number:** Stand-alone systems do not need to be set up; The parallel system is divided into two cases:

1. Each energy storage controller is configured with an ATS. In this case, the communication station number must be the same as the 485 address of the corresponding energy storage controller.
2. All energy storage controllers share one ATS and do not need to be configured.

**ATS Communication Station Number Enable:** If you need to set the ATS communication station number, set Enable to 1 and then change the ATS communication station number. After the modification, the enable bit must be set to 0. Start only the energy storage controller and ATS. After the Settings are complete, power off and set other devices to avoid duplicate delivery.


**ATS Numbers:** Number of ATS in the system.

**AC OverVolt time(20ms):** In off-grid mode, when the energy storage controller triggers the delayed protection of AC overvoltage, do not modify it to avoid affecting the stable running of the system.

**Grid charging power:** The maximum charging power of the grid to the battery can limit the charging power of the grid to the battery

**Cut-off charging power:** When the discharge cut-off voltage or SOC is reached, the battery is charged at a trickle to maintain the battery voltage and prevent the battery voltage from being too low.

**Grid Charge Cutoff SOC/Grid Charge Cutoff Volt:** When the grid power is sufficient and the grid power is allowed to charge, the amount of charging to the new grid charging cutoff SOC and grid charging cutoff voltage is realized in the battery first, economic mode trough, and time scheduling trough. When the grid charging cutoff SOC or grid charging cutoff voltage is reached, only PV or CP charges the battery, and the grid does not charge the battery.



This page will be set according to the technical agreement before delivery


This page is the economic mode time period setting page, which only takes effect in economic mode. The time period after 24 o'clock must be divided into two settings. For example, 20:00-6:00 is the valley period, which needs to be set as 20:00-24:00, 00:00-6:00.



The page without instructions is factory preset parameter, please do not modify. If the subsequent scheme changes, please modify the parameters under the guidance of us.

## 2. Calibration parameters:

Modification of calibration parameters: when it is modified to 0, it means that the function is not valid; when modified to 1, it means that the function is valid; the modification enabling does not need to be saved manually, parameters are saved automatically. If the modification fails to save automatically and the function cannot take effect, please contact us.



**Island protection enable:** it is a protection to prevent the inverter from not correctly switching into off grid mode in case of grid abnormality. Enter 0-9,0 means disable; 1-9 means level, suggested not to set too high.

**Manual adjustment enable:** only used to modify important parameters, do not open it at ordinary times. Please set under the guidance of us.

**Bypass cabinet enable:** when inverter is used with ATS produced by us, the bypass cabinet enabling needs to be modified to 1; otherwise, set to 0. When using ATS of other manufacturers, set it to 2, grid and generators will be distinguished through dry contact signal detection (see chapter 5.6 for specific operation methods).

**BMS communication enable:** when inverter communicates with the battery in BMS, set it to 1; otherwise, set to 0.


**Anti\_backflow enable:** when set to 1, inverter will not feed power to grid; when set to 0, inverter will feed power to grid.

**Generator enable:** when the input end of the power grid of the inverter is connected to diesel generator, generator enable should be set to 1, otherwise set to 0. When using with ATS to connect generator, it should also be set to 1 as well as the Bypass cabinet enable.

**Grid and PV charging enable:** When set to 1, in the battery priority mode, PV and grid charge battery together. When it is set to 0, it uses only PV to charge battery when solar energy is sufficient, and use grid power to charge only when there is no solar energy.

**Parallel enable:** when it is set to 1, parallel function is enabled. All the parallel units needs to be set to 1.

**Factory restore:** when set to 1, reset the power information recorded in the data page. Parameter settings will not be modified.



**Number of parallel machine:** number setting of parallel system. When 2 inverters in parallel, set as 2; when three units set as 3.

**Parallel redundant number:** Maximum number of faulty machine, can be set to 0 or 1. When set to 0, if one machine in the parallel system goes down, all machines will turn into faulty mode; If set to 1, when the faulty number is less than 1, the other machine keeps running(max. faulty number that can be supported is 1).


**System ID Sign:** Background monitoring distinguishes whether devices are the same system and uses this to collect statistics. Devices of the same system set the same non-zero number here.

**Parallel address:** to distinguish each equipment in the system, can be set to 1, 2, 3...

**Limit power exporting to grid:** is the upper limit of the maximum power that can be fed into a machine from the grid.

**BMS voltage judgment Enable:** Set this parameter to 1 when the SOC calculated by BMS has poor accuracy and affects system operation. Otherwise, set this parameter to 0.

**Force charge enable:** set to 1 when matching with the battery, otherwise set to 0.



**Bat to Non-critical Enable:** Set '1' supply power to non-critical loads via the battery.


**Meter communication station number:** Communication address of meter.

**Meter Com Switch Enable:** Set 1HPS to send instructions to communicate with the meter; Set 0 communicate with the meter by a third party or collector.

**CT ratio of meter:** The CT ratio of meter.

**DC main contactor detection Enable:** Factory default, do not modify.

**Meter Com Switch Enable:** Set '1', HPS sends command to communicate with the meter; set '0', the third party or collector communicates with the meter.



● Grid connection mode selection page


Set to 0, run load priority mode when grid connected

Set to 1, run battery priority mode when connected to grid

Set to 2, run economic mode when connected to grid

Set to 3, set the running time scheduling mode to 10 when connected to the grid, and set it to run smart electricity meter mode when connected to the grid.


● This takes effect when generator enable set to 0. When generator enable is set to 1, it will enter generator mode by default under grid connection. When using with ATS and enable the bypass cabinet, the system runs at two modes at the same time(one of the above four modes and DG mode).



If user has customized the operation mode, please do not modify it.  
The page without instructions is the factory preset parameter, please do not modify.  
If the subsequent scheme changes, please modify the parameters under the guidance of us.


### 3. Power grid management

The value on this page are important factory preset parameters. Please do not modify them without the consent of us. We won't be responsible for the consequences caused by changing the value.



If the subsequent scheme changes, please modify the parameters under the guidance of us.

#### 4. Factory settings



The value on this page are important factory preset parameters. Please do not modify them without consent of us.




The page without instructions is the factory preset parameter, please do not modify. If the subsequent scheme changes, please modify the parameters under the guidance of us.

#### 7.2.5 Historical information

Clicking "historical information" can enter into the sub-menu of the "historical information".

The submenu includes: current fault, historical fault. Via clicking button you can enter the corresponding submenu interface.



History fault: all the common history of failure details can be found by flipping the page up and down.

The common fault information, see table 7.3.

#### 7.2 LCD display information schedule

General history failure table

| NO | Information                |                   |
|----|----------------------------|-------------------|
|    | English                    | Chinese           |
| 1  | PV_Inverse_Failure         | PV接反永久故障          |
| 2  | IGBT_Failure               | IGBT永久故障          |
| 3  | EEPROM_Write_Failure       | EEPROM写永久故障       |
| 4  | EEPROM_Read_Failure        | EEPROM读永久故障       |
| 5  | AC_MainContactor_Failure   | 主接触器永久故障          |
| 6  | AC_SlaveContactor_Failure  | 辅接触器永久故障          |
| 7  | GFDI_Failure               | GFDI永久故障          |
| 8  | GFCI_Failure               | GFCI永久故障          |
| 9  | RISO_Failure               | 绝缘阻抗永久故障          |
| 10 | PV_VoltHigh_Fault          | PV电压高故障           |
| 11 | Bypass_Communication_Fault | 旁路柜通信故障           |
| 12 | PV_CurrHigh_Fault          | PV电流过流故障          |
| 13 | BMS_Communication_Fault    | BMS通信故障           |
| 14 | PV_Insulation_Fault        | PV对地绝缘阻抗故障        |
| 15 | BMS_Fault                  | BMS故障             |
| 16 | DC_OCP_Fault               | 直流过流故障 (Trip)     |
| 17 | Smoke_alarm_Fault          | 烟雾报警故障            |
| 18 | INT_PV_OverVolt_Fault      | PV过压故障 (INT)      |
| 19 | INT_PV_OverCurr_Fault      | PV过流故障 (INT)      |
| 20 | IGBT_Converter_Fault       | 控制器IGBT故障         |
| 21 | IGBT_Buck_Fault            | Buck IGBT故障       |
| 22 | Converter_L_OCP_Fault      | 控制器电感过流故障 (Trip)  |
| 23 | Buck_L_OCP_Fault           | Buck电感过流故障 (Trip) |
| 24 | AC_NoUtility_Fault         | 交流无市电故障           |
| 25 | AC_GridPhaseSeque_Fault    | 交流电网相序反故障         |
| 26 | AC_PLL_Fault               | 交流锁相故障            |
| 27 | AC_Volt_Unbalance_Fault    | 交流电压不平衡故障         |
| 28 | AC_Curr_Unbalance_Fault    | 交流电流不平衡故障         |
| 29 | AC_WU_OverVolt_Fault       | 交流WU过压故障          |



| NO | Information                   |                  |
|----|-------------------------------|------------------|
|    | English                       | Chinese          |
| 30 | AC_WU_UnderVolt_Fault         | 交流WU欠压故障         |
| 31 | AC_VW_OverVolt_Fault          | 交流VW过压故障         |
| 32 | AC_VW_UnderVolt_Fault         | 交流VW欠压故障         |
| 33 | AC_UV_OverVolt_Fault          | 交流UV过压故障         |
| 34 | AC_UV_UnderVolt_Fault         | 交流UV欠压故障         |
| 35 | AC_OverFreq_Fault             | 交流过频故障           |
| 36 | AC_UnderFreq_Fault            | 交流欠频故障           |
| 37 | AC_GridCurr_DcHigh_Fault      | 电网直流量高故障         |
| 38 | GridCurr_High_Fault           | 电网电流高故障          |
| 39 | Buck_Module_OverTemp_Fault    | Buck模块过温故障       |
| 40 | Converter_L_OverTemp_Fault    | 变流器电感过温故障        |
| 41 | Buck_L_OverTemp_Fault         | Buck电感过温故障       |
| 42 | Transformer_OverTemp_Fault    | 变压器过温故障          |
| 43 | LowTemp_Fault                 | 低温故障             |
| 44 | EPO_Stop                      | 紧急停机             |
| 45 | KeyEmergencyStop              | 手动关机             |
| 46 | LcdEmergencyStop              | LCD关机            |
| 47 | DC_MainContactor_Fault        | 直流主接触器故障         |
| 48 | PV_Thunder_Fault              | PV直流防雷器故障        |
| 49 | AC_Thunder_Fault              | 交流防雷器故障          |
| 50 | DC_SoftStart_Fault            | DC软启故障           |
| 51 | INT_ConverterL_OverCurr_Fault | 变流器电感过流故障 (INT)  |
| 52 | INT_BuckL_OverCurr_Fault      | Buck电感过流故障 (INT) |
| 53 | Batt_OverVolt_Fault           | 电池过压故障           |
| 54 | Batt_UnderVolt_Fault          | 电池欠压故障           |
| 55 | Batt_OverCurr_Fault           | 电池过流故障           |
| 56 | Batt_OverCharge_Fault         | 电池过充故障           |
| 57 | Fault_Feedback_Warning        | 故障反馈告警           |
| 58 | Batt_UnderVolt_Warning        | 电池欠压告警           |
| 59 | AC_WU_OverVolt_Rmt_Warning    | 交流旁路WU过压         |
| 60 | AC_WU_UnderVolt_Rmt_Warning   | 交流旁路WU欠压         |
| 61 | AC_VW_OverVolt_Rmt_Warning    | 交流旁路VW过压         |
| 62 | AC_VW_UnderVolt_Rmt_Warning   | 交流旁路VW欠压         |
| 63 | AC_UV_OverVolt_Rmt_Warning    | 交流旁路UV过压         |
| 64 | AC_UV_UnderVolt_Rmt_Warning   | 交流旁路UV欠压         |

## 8.1 Power on steps

After installation and system settings are inspected, inverter can be started for operation.

### First run

The first operation steps are as follows:

1. Turn on the PV, battery, AC input and power supply micro breaks, and do not turn on the AC output switch before the system operates normally to avoid any impact on the load;
2. Bypass switch shall be closed when it is in normal operation;
3. Check whether the screen sampling data is abnormal and consistent with the actual situation;
4. Check whether the battery parameter setting is consistent with the actual battery, if not please modify.
5. If the battery has BMS, check whether the BMS is enabled and normal.
6. If the grid input end is connected to generator, check whether generator is enabled.
7. If it is equipped with ATS manufactured by us, check whether the bypass cabinet is enabled.
8. Check the history information page of the screen, and check whether there are serious faults according to the general faults in Chapter 8.3.
9. After checking, turn the knob to "on", click "on" on the LCD" on / off "page, and wait for the machine to enter" grid connection "; if the site is off grid, it will enter" off grid mode "after starting;
10. During operation, observe whether the data displayed on the screen is normal and whether there is fault information reported, and whether the machine has abnormal noise and smell; if any abnormal situation occurs, please stop the machine immediately for inspection.



### Warning!

The bypass switch is only used for maintenance. Please do not turn it on during normal operation.

### Manual shutdown

1. After clicking the LCD shutdown button to shut down the machine manually, it must be turned on manually through the start button (on) on the LCD; if the machine is turned off by turning the knob to "off", turn the HPS knob to "on" first, and then click the "on" button on the LCD "switch on" page to start the machine, otherwise inverter cannot start automatically.
2. The inverter is still electrified after manual shutdown.

## 8.2 Pilot operation completion

The following procedures shall be carried out after the inverter is normally in operation.

Procedure 1: Inspect whether abnormality exists in the inverter, such as excessive noise, excessive heat, abnormal smell or smoke.

Procedure 2: Measure whether inverter voltage, current and THD are stable.

Procedure 3: Operate LCD control panel and inspect whether it displays normally and accurately.

Procedure 4: Test whether it conforms to the preset operation logic.

By now, the pilot operation of inverter is fully completed, and we can enter the daily operational maintenance.

## 8.3 General troubleshooting

If there is a fault during the operation, please click the LCD "history information" page to view the fault information. The following are the common fault analysis and handling steps of HPS:

1. Key emergency stop: turn HPS panel knob to "off"

Handling steps: the knob is shut down normally, no need to handle.

2. LCD emergency stop: click "off" on HPS screen

Processing steps: the screen is shut down normally, no need to handle.

3. Emergency stop: emergency stop button pressed.

Handling steps: release the emergency stop button in case of no other abnormalities.

4. Batt\_UnderVolt\_Fault:

Possible reasons:

a. The battery voltage sampled on the screen reaches the under-voltage protection condition and triggers it.

b. The switch of battery on battery side or the on the energy storage controller is not turned on.

c. If this fault occurs during operation, the battery voltage may be pulled down due to high-power output, or the battery itself may be defective.

d. If it is a battery with BMS, this fault will also occur if the lowest cell voltage of the battery unit transmitted by the BMS to the energy storage controller reaches the protection condition.

Processing steps:

a. First, check the battery connection, screen sampling error, and battery parameter settings.

b. If it is a battery with BMS, check whether the BMS data meets the protection conditions.

c. If there is no problem with the above, please contact us for assistance.

5. Batt\_OverVolt\_Fault:

Possible reasons:

a. The battery voltage sampled on the screen reaches the overvoltage protection trigger condition.

b. If it is a battery with BMS, this fault will also occur if the highest cell voltage of the battery unit transmitted by the BMS to the energy storage controller reaches the trigger protection condition.

Processing steps:

a. Check whether the number of battery cells and the overvoltage protection value are set correctly. If not, please set the parameters correctly.

If the parameters are correct due to the overvoltage of the battery itself, please contact us for assistance.

6. Batt\_OverCharge\_Fault: the battery charging current is higher than the maximum charging current.

Processing steps: check whether the battery charging current setting value and the maximum charging current

value are reasonable. The maximum charging current value of the battery shall be set according to

the recommendations given by the battery manufacturer. The setting value of the battery charging current

shall be less than the maximum charging current protection value.

7. Batt\_OverCurr\_Fault: the battery discharge current is higher than the maximum discharge current

Processing steps: check whether the maximum discharge current value of the battery is reasonable, multiply the maximum discharge current by the battery voltage, calculate the maximum discharge power of the battery, see whether it is less than the load power, if yes, reduce the load power.

8. BMS\_Fault: secondary or tertiary battery failure

Processing steps:

A. check the specific faults reported by BMS

B. contact the battery manufacturer to solve the problem

C. restart after troubleshooting

9. BMS\_Communication\_Fault: the energy storage inverter did not receive CAN data sent by battery BMSA

Processing steps:

A. check whether the CAN line of ATS is connected to the CAN-A port of the inverter's control board.

B. check if the L and H CAN line are connected reversely.

C. check whether the CAN line is interfered. Suggest to use sampling shielded communication line.

D. use the CAN box to check whether there is data sent by the BMS on the bus.

E. if the communication still fails, contact US.

10. Bypass\_Communication\_Fault: the energy storage inverter did not receive can data sent by bypass cabinet

Processing steps:

- A. check whether the CAN line of ATS is connected to the CAN-B port of the inverter's control board.
- B. check whether the L and H CAN line is connected reversely
- C. check whether the CAN line is interfered. Suggest to use sampling shielded communication line.
- D. use CAN box to check if there is data sent by ATS on the bus.
- E. if communication still fails, contact us

11. AC\_NoUtility\_Fault: no AC voltage.

Processing steps: generally, this fault will not fade out because there is no output due to other reasons.

12. AC\_OverFreq\_Fault: the power grid frequency exceeds the upper limit, and the energy storage inverter enters off grid state.

Processing steps: check whether the upper limit of power grid frequency is reasonable. If yes, wait until it returns to normal, the inverter will automatically enter into grid connection state.

13. AC\_UnderFreq\_Fault: the power grid frequency is lower than the lower limit, and the energy storage inverter enters the off grid state.

Processing steps: check whether the lower limit of power grid frequency is reasonable. If yes, wait until the power grid frequency returns to normal, HPS will automatically enter into grid connection state.

14. AC\_UV\_OverVolt\_Rmt\_Warning: when the utility grid voltage is higher than the upper limit, the energy storage inverter enters off grid state.

Processing steps: check whether the upper limit setting of power grid voltage is reasonable. If yes, wait until the power grid voltage returns to normal, and HPS will automatically enter into grid connection state.

15. AC\_VW\_OverVolt\_Rmt\_Warning: when the grid voltage is higher than the upper limit, HPS enters off grid state.

Processing steps: check whether the upper limit setting of power grid voltage is reasonable. If yes, wait until the power grid voltage returns to normal, and HPS will automatically enter into grid connection state.

16. AC\_WU\_OverVolt\_Rmt\_Warnin: when the grid voltage is higher than the upper limit, HPS enters off grid state.

Processing steps: check whether the upper limit setting of power grid voltage is reasonable. If yes, wait until the power grid voltage returns to normal, and HPS will automatically enter into grid connection state.

17. AC\_UV\_UnderVolt\_Rmt\_Warning: when the grid voltage is lower than the lower limit, HPS enters off grid state.

Processing steps: check whether the lower limit setting of power grid voltage is reasonable. If yes, wait for the power grid voltage to return to normal, and HPS will automatically enter into grid connection state.

18. AC\_VW\_UnderVolt\_Rmt\_Warning: when the grid voltage is lower than the upper limit voltage, HPS enters off grid mode.

Processing steps: check whether the lower limit setting of power grid voltage is reasonable. If yes, wait for the power grid voltage to return to normal, and HPS will automatically enter into grid connection state.

19. AC\_WU\_UnderVolt\_Rmt\_Warning: when the grid voltage is lower than the upper limit voltage, HPS enters off grid state.

Processing steps: check whether the lower limit setting of power grid voltage is reasonable. If yes, wait for the power grid voltage to return to normal, and HPS will automatically enter into grid connection state.

20. AC\_GridPhaseSeque\_Fault: reverse phase sequence connection of power grid

Processing steps: check the three lines of phase sequence U V W of the utility grid, which are corresponding to A B C connected to the AC input terminal of inverter.

21. OverTemp\_Fault: the temperature inside of the machine is too high.

Processing steps:

- A. check whether the power supply micro break of the inverter is turned on. If not, turn it on.
- B. check whether HPS air inlet and outlet are blocked, and clean dust regularly.
- C. wait for the machine to cool down, the fault is eliminated and inverter restart normally, and observe whether the fan works when the temperature reaches 60 °C. If not, please contact us.

Regarding other faults, please contact relevant professionals of us.

## 8.4 Power off steps



### CAUTION!

After the inverter is completely powered off, the general DC switch at battery side and the Grid switch at grid side still maintain voltage. If operations are needed, please be sure to cut off the outer power completely, and wait for not less than 5 minutes.

1. Click the OFF button on LCD or turn the off-on knob from ON to OFF.
2. Cut off DC SWITCH PV input and Battery input.
3. Cut off AC SWITCH AC input and AC output.



### CAUTION!

It is normal for the inverter to give alarm during power off. The power down steps can be continued.

## 9 Routine Maintenance

### 9.1 Regular maintenance







Due to the influence of environment temperature, humidity, dust and vibration, the devices inside the inverter will be aged and worn, which will lead to potential failure inside the machine. Therefore, it is necessary to carry out daily and regular maintenance to ensure its normal operation and service life. All measures and methods to help the inverter in good working condition belong to the scope of maintenance work.

#### 9.1.1 Safety precautions

- (1) Only qualified and authorized personnel can maintain the inverter.
- (2) When carrying out maintenance work, do not leave the screws, washers and other metal parts in the inverter, otherwise the equipment may be damaged.
- (3) If only the circuit breaker is opened, the cable connection terminal inside the inverter is still electrified.
- (4) Before opening the cabinet door and starting the formal maintenance work, it is necessary to not only disconnect the circuit breaker, but also disconnect the front and rear level circuit breakers of the inverter.
- (5) After the inverter stops operation, please wait at least 5 minutes before operating.
- (6) Disconnect all external connections of the inverter and the internal power supply of the equipment.
- (7) Ensure that the inverter is not inadvertently recharged.
- (8) Use a multimeter to ensure that the inverter is completely electrically neutral inside.
- (9) Make necessary grounding and short circuit connections.
- (10) Use insulating material cloth to cover the parts near the operation part that may be electrified.

#### 9.1.2 System maintenance

Tools to be used during maintenance



|                                                                                     |                                 |
|-------------------------------------------------------------------------------------|---------------------------------|
|  | Cell phone that can take photos |
|  | Multimeter                      |
|  | Thermometer                     |
|  | Pen and paper                   |
|  | Spanner, screwdriver etc        |
|  | Thermal imager                  |

### 2.1 Maintenance and inspection checklist for running system

When recording inspection and maintenance, inspection shall be carried out one by one following the table sequence, and the faulty items shall be described accordingly.

Please refer to Capture 10.3 Maintenance and inspection checklist for non-shutdown system.

After the inspection record is completed, photos of the operation status in home page and historical information page shall be taken for record, as shown in the following figures:



### 2.2 Maintenance and inspection checklist for shutdown system

Please refer to Capture 10.4 Maintenance and inspection checklist for shutdown system.

#### 9.1.3 Relative operations



#### CAUTION!

All maintenance operations must be carried out in the condition that DC side and AC side of the inverter, PV module and AC distribution cabinet switch are all disconnected. Maintenance must be proceeded only after AC and DC disconnected for at least 5 minutes, in order to avoid electric shock!

Only professional technicians familiar with the system operation can perform such operation.

## Disconnect the circuit breaker

Operate the DC switch of PV input and battery input to disconnect HPS from the PV and battery. And operate AC input and AC output switches to disconnect HPS from AC sources. Make sure that HPS won't switch on accidentally. Test with a multimeter to make sure the device is disconnected and with zero voltage. Even if HPS has been disconnected from the grid / main power supply, battery and PV, some of the internal components (such as capacitors) still have residual voltage and discharge slowly, so please wait at least 5 minutes after the circuit breaker is disconnected and use the multimeter to measure and confirm the safety before continuing operation.

## How to use bypass switch

If the HPS fails and cannot continue to operate, it needs to be shut down for maintenance, while the load connected to the HPS needs to continue working, the bypass switch can be used to keep the load work uninterruptedly under the power supply of power grid or generator, and the maintenance personnel can carry out maintenance work safely.

Step 1: turn on the bypass switch in case of machine failure.

Step 2: turn off the switches of "AC input", "AC output", "PV input" and "battery input". At this time, the AC and DC power are disconnected from HPS, and the load is all supplied by the power grid, after the residual power is discharged, maintenance work can be carried out.

### Note:

1. After power off, wait for 5 minutes to confirm safety before carrying out maintenance work.
2. Use the multimeter to ensure safety before disassembling and other work.

## Function and safety parameters

Do not change parameters of HPS without the authorization of the local power supply company and the instruction of us. Unauthorized change of functional safety parameters may cause injury to personnel or inverter damage, in this case, We will not provide warranty services.

## Replace the dust screen

During the use of HPS, the dust on the top shall be cleaned regularly, and the dust screen at the air inlet shall be cleaned or replaced. During the cleaning, HPS needs to be power-off.

Replacement method of dust screen: the dust filter cotton on the door panel can be directly pulled up for cleaning and replacement.

## 9.2 Waste disposal

The inverter will not cause environmental pollution, since the all the components meet the requirements of environmental protection. According to environmental protection requirements, user shall dispose the inverter in accordance with the relevant laws and regulations.

## 10.1 Specification

|                                 |                                                                                                                               |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| Model                           | HPS30                                                                                                                         |
| <b>PV parameter</b>             |                                                                                                                               |
| PV rated power                  | 33KW                                                                                                                          |
| Max. PV power                   | 45KW                                                                                                                          |
| Max. PV open circuit voltage    | 1000V                                                                                                                         |
| PV MPPT voltage range           | 480Vdc-800Vdc                                                                                                                 |
| Max.PV input current            | 90A                                                                                                                           |
| <b>Battery parameter</b>        |                                                                                                                               |
| Battery operating voltage range | 352V-600V                                                                                                                     |
| Max battery charge current      | 100A                                                                                                                          |
| Max battery discharge current   | 93A                                                                                                                           |
| Max battery charge power        | 45KW                                                                                                                          |
| Max battery discharge power     | 33kw                                                                                                                          |
| <b>AC output parameter</b>      |                                                                                                                               |
| Rated voltage                   | 400Vac                                                                                                                        |
| Rated current                   | 43A                                                                                                                           |
| Rated power                     | 30KW                                                                                                                          |
| Rated frequency                 | 50/60Hz                                                                                                                       |
| Frequency Range                 | 45-55Hz/55-65Hz                                                                                                               |
| Max. AC output power            | 33KVA                                                                                                                         |
| Max. AC input power             | 60KVA                                                                                                                         |
| Power factor                    | 0.8lagging—0.8leading                                                                                                         |
| THDI                            | <3%(Full load)                                                                                                                |
| THDU                            | ≤2%                                                                                                                           |
| Overload capacity               | 110%-10 mins,120%-1 min                                                                                                       |
| <b>Other parameter</b>          |                                                                                                                               |
| Ingress Protection              | IP20(Outdoors)                                                                                                                |
| Protective class                | Class I                                                                                                                       |
| Mains over voltage category     | OVC III                                                                                                                       |
| PV over voltage category        | OVC II                                                                                                                        |
| Demand response mode            | DRM0-8 (optional)                                                                                                             |
| Inverter topology               | Isolated                                                                                                                      |
| Noise emission                  | <65dB (A) @1m                                                                                                                 |
| Cooling                         | Intelligent air cooling                                                                                                       |
| Humidity                        | 0%-95% non-condensing                                                                                                         |
| Maximum altitude                | 6000 (derate over 3000m)                                                                                                      |
| Build-in transformer            | yes                                                                                                                           |
| Operating temperature           | -25°C+55°C                                                                                                                    |
| Active anti-islanding method    | Shifting the frequency of the inverter away from nominal conditions in the absence of a reference frequency (frequency shift) |
| <b>Communication</b>            |                                                                                                                               |
| LCD display                     | Touch screen LCD                                                                                                              |
| Communication interface         | RS485/CAN                                                                                                                     |

1.5 times rated PV output: HPS supports 1.5 times rated PV output at most, but the following two conditions(Battery voltage, PV MPPT voltage) need to be met.

| Model  | Battery voltage (current actual voltage) | PV MPPT voltage                                | Inrush current | Max.output overcurrent | Feedback current |
|--------|------------------------------------------|------------------------------------------------|----------------|------------------------|------------------|
| HPS30  | Above 450V                               | Exceed the max. battery voltage and above 500V | 47.6A          | 52A                    | 0A               |
| HPS50  | Above 500V                               | Exceed the max. battery voltage and above 550V | 79.3A          | 86.6A                  | 0A               |
| HPS100 | Above 500V                               | Exceed the max. battery voltage and above 650V | 158.7A         | 173.2A                 | 0A               |
| HPS120 | Above 520V                               | Exceed the max. battery voltage and above 550V | 190.5A         | 207.8A                 | 0A               |
| HPS150 | Above 500V                               | Exceed the max. battery voltage and above 550V | 238.1A         | 259.8A                 | 0A               |

There are diodes on the PV side to prevent PV reflux. In case of short circuit, HPS will immediately disconnect all contactors and circuit breakers to prevent other equipment from being affected.

Isolation transformer functions and specifications

1. Buck-boost function: Meet the minimum battery voltage of 352V.
2. Electrical isolation: isolate the primary and secondary to ensure safety.
3. Star-delta transformation: forming the N line.

|                         |                     |                 |
|-------------------------|---------------------|-----------------|
| Model                   | HPS30               |                 |
| Rated capacity          | 30KVA               |                 |
| Rated frequency         | 50/60Hz             |                 |
| Primary rated voltage   | 200V                |                 |
| Secondary rated voltage | 400V                |                 |
| Primary rated current   | 86.6A               |                 |
| Secondary rated current | 43.3A               |                 |
| Connection group        | Dyn11               |                 |
| No-load loss            | 185W                |                 |
| Load loss(75°C)         | 875W                |                 |
| Temperature rise        | ≤75K                |                 |
| Cooling                 | AF                  |                 |
| Insulation grade        | H                   |                 |
| Ingress protection      | IP00                |                 |
| Grounding mode          | Neutral ungrounding |                 |
| Dielectric strength     | 3000V,60S,≤15mA     | 3000V,60S,≤20mA |

## 10.2 Factory warranty

### ● Warranty period

The warranty period of this product is one year. If otherwise specified in the contract, the contract shall prevail.

During the warranty period, the customer shall show the invoice and date of purchase to the service personnel. At the same time, the nameplate mark on the product shall be clear and visible, otherwise, we have the right not to provide warranty service.

### ● Warranty conditions

In the event of failure during the warranty period, we will repair or replace the product free of charge; The customer shall Set aside some time to repair the faulty machine

### ● Liability exemption

In case of the following circumstances, We have the right not to conduct warranty:

1. Products without logo of our logo.
2. The product or component that has exceeded the valid warranty period.
3. Failure or damage (such as high temperature, low temperature, too wet or dry, high altitude, unstable voltage or current, etc.) caused by working in beyond-specified environment or wrong installation, storage or use that violates the instructions.
4. Failure or damage caused by unauthorized installation, repair, modification or disassembly. except for those authorized by us.
5. Failure or damage caused by using components that not supplied by us.
6. Failure, damage or transportation damage caused by accident or human factors (operation error, scratching, carrying, bumping, improper voltage connection etc.).
7. Failure or damage caused by force majeure (such as earthquake, lightning, fire etc.).
8. Failures or damages caused by other factors rather than quality problems of the supplied product itself(including components).

### 10.3 Maintenance and inspection checklist for running system

| No. | Category                      | Check item                                                                                                                                                                                | Method/Tool                      | Standard                                                           | Result                                                               | Problem description | Check frequency |
|-----|-------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------|--------------------------------------------------------------------|----------------------------------------------------------------------|---------------------|-----------------|
| 1   | System operation status check | Whether the LCD display of the machine is in normal operation                                                                                                                             | Visual inspection screen         | Operation status display is not "fault" or "serious fault"         | <input type="checkbox"/> Normal<br><input type="checkbox"/> Abnormal |                     | Once a month    |
| 2   |                               | Whether there is error recorded in history that caused shutdown                                                                                                                           | Visual inspection screen         | No error caused shutdown                                           | <input type="checkbox"/> Normal<br><input type="checkbox"/> Abnormal |                     |                 |
| 3   |                               | Whether the data transmission of monitoring device is normal                                                                                                                              | Monitoring web page / APP        | Monitoring connection and data transmission are normal             | <input type="checkbox"/> Normal<br><input type="checkbox"/> Abnormal |                     |                 |
| 4   |                               | Whether the fan rotates normally and the air outlet is normal (first check whether the temperature collected by the equipment reaches the fan opening condition, which normally is 60 °C) | Visual inspection Thermal imager | Normal rotation, normal air output                                 | <input type="checkbox"/> Normal<br><input type="checkbox"/> Abnormal |                     |                 |
| 5   |                               | Whether the equipment has abnormal smell or sound                                                                                                                                         | Smell, listen                    | No abnormal sound or smell                                         | <input type="checkbox"/> Normal<br><input type="checkbox"/> Abnormal |                     |                 |
| 6   |                               | Emergency stop button(when the system is in standby mode)                                                                                                                                 | Manual                           | The circuit breaker trips after pressing the emergency stop button | <input type="checkbox"/> Normal<br><input type="checkbox"/> Abnormal |                     |                 |

### 10.4 Maintenance and inspection checklist for shutdown system

| No. | Category                                       | Check item                                                                                      | Method/Tool                   | Standard                           | Result                                                               | Problem description | Check frequency |
|-----|------------------------------------------------|-------------------------------------------------------------------------------------------------|-------------------------------|------------------------------------|----------------------------------------------------------------------|---------------------|-----------------|
| 1   | System cleaning                                | Whether there is water leakage or other foreign matters in the room or container                | Visual inspection             | No water leakage or foreign matter | <input type="checkbox"/> Normal<br><input type="checkbox"/> Abnormal |                     | Once a month    |
| 2   |                                                | Whether there are rodents and insects such as rats, geckos, cockroaches and ants in the cabinet | Visual inspection             | No animals or insects              | <input type="checkbox"/> Normal<br><input type="checkbox"/> Abnormal |                     |                 |
| 3   | System cable connection (power-off inspection) | Whether the power cable connection is loose                                                     | Manual /Wrench                | No looseness                       | <input type="checkbox"/> Normal<br><input type="checkbox"/> Abnormal |                     | Once a month    |
| 4   |                                                | Whether the communication cable connection is loose                                             | Manual bolt driver            | No looseness                       | <input type="checkbox"/> Normal<br><input type="checkbox"/> Abnormal |                     |                 |
| 5   |                                                | Check equipment ground connection                                                               | Visual inspection /Multimeter | <=4Ω                               | <input type="checkbox"/> Normal<br><input type="checkbox"/> Abnormal |                     |                 |
| 6   |                                                | whether the external connection of the equipment is damaged                                     | Visual inspection             | No damage                          | <input type="checkbox"/> Normal<br><input type="checkbox"/> Abnormal |                     |                 |
| 7   | Internal cleaning                              | whether there is moisture or condensation inside the cabinet                                    | Visual inspection             | No condensation, no moisture       | <input type="checkbox"/> Normal<br><input type="checkbox"/> Abnormal |                     | Once a month    |
| 8   |                                                | Whether there is obvious dust inside the cabinet                                                | Visual inspection             | No obvious dust                    | <input type="checkbox"/> Normal<br><input type="checkbox"/> Abnormal |                     |                 |
| 9   |                                                | Whether the front and rear dust screens has blockage                                            | Visual inspection             | No blockage                        | <input type="checkbox"/> Normal<br><input type="checkbox"/> Abnormal |                     |                 |
| 10  | Internal cleaning                              | Whether there is obvious damage inside the equipment                                            | Visual inspection             | No damage                          | <input type="checkbox"/> Normal<br><input type="checkbox"/> Abnormal |                     | Once a month    |
| 11  |                                                | whether there is obvious rust inside the cabinet                                                | Visual inspection             | No rust                            | <input type="checkbox"/> Normal<br><input type="checkbox"/> Abnormal |                     |                 |
| 12  |                                                | Safety signs                                                                                    | Visual inspection             | Safety signs are not shed          | <input type="checkbox"/> Normal<br><input type="checkbox"/> Abnormal |                     |                 |

**Note:** the table only indicates the recommended maintenance frequency of the product. The actual frequency shall be determined according to the specific installation environment. The scale of power station, location and site environment will affect the maintenance frequency. If the operation environment is windy and dusty, it is necessary to shorten the period and increase the frequency.

## 10.5 EMS mode RS485 command (EMS mode is DRM mode)

|                       | HPS30                   |
|-----------------------|-------------------------|
| Power on command      | 01 06 00 00 00 01 48 0A |
| Power off command     | 01 06 00 00 00 00 89 CA |
| Turn on EMS mode      | 01 06 00 20 00 01 49 C0 |
| Turn off EMS mode     | 01 06 00 20 00 00 88 00 |
| Rectify AC→DC         | 01 06 00 22 00 01 E8 00 |
| Inverter DC→AC        | 01 06 00 22 00 00 29 C0 |
| 0% rater DC/AC power  | 01 06 00 23 00 00 78 00 |
| 25% rater DC/AC power | 01 06 00 23 00 08 79 C6 |
| 50% rater DC/AC power | 01 06 00 23 00 0F 38 04 |
| 75% rater DC/AC power | 01 06 00 23 00 17 38 0E |
| 50% rated PV power    | 01 06 00 21 00 0F 99 C4 |
| 100% rated PV power   | 01 06 00 21 00 1E 59 C8 |

RS485 instruction formula description

AB CD EF GH IJ KL MN OP

AB:485 communication address

CD:Function code

EF GH: Register address

IJ KM:Value

MN OP:CRC check value of the first 6 bits

The appendix only shows part of the power section instructions. Please write the required instructions according to the 485 instruction formula and control the ATESS Modbus RTU protocol.