



SHENZHEN ATESS POWER TECHNOLOGY CO.,LTD

GROWATT-ATESS Industrial Park, No.23 Zhulongtian Road, Shuitian Community,
Shiyan Street, Baoan District, Shenzhen

Tel: +86 755 2998 8492

Web: www.atesspower.com

Email: info@atesspower.com

Revised date: 2025-03-21



ATESS EVD-40D

**DC EV Charging Station
User Manual**

Disclaimer

This user manual is copyrighted by ATESS Power Technology Co., Ltd. (here in after referred to as “ATESS”). No company or person may extract or copy part or all of this user manual without the written permission of ATESS Power Technology Co., Ltd. Content must not be transmitted in any form, including materials and publications.

All rights reserved.

ATESS has the final right to interpret this user manual. The information in this manual is subject to change without notice.

Thank you for choosing ATESS!

ATESS EVD series intelligent DC EV Charging station is a device that provides high-efficiency, safe and stable DC power supply for electric vehicles, which has a friendly man-machine interface and integrates corresponding functions of control, billing, communication and security protection. The charging equipment uses OCPP 1.6JSON open protocol for communication with back-office server, thus to realize functions such as reservation and network payment via mobile APP. Diversified communication options, including wired Ethernet, WIFI, 4G, wireless, are provided for customers to conveniently connect the device to a charging network. This product supports CCS2. Each connector works independently. Up to 2 EVS could be charged at the same time. All the above features make it most suitable for outdoor charging.

We sincerely hope that this product can meet your needs, and we welcome and value your feedback and suggestions on the performance and function of the product. We will continuously improve the quality of our products and services.

Contents

1 Product Description

2 Packaging List

3 Installation and Wiring


4 Parameter Configuration

5 Operation Instruction and LCD Description

6 Specification

7 Appendix

1 Product Description




1. HMI;
2. POS (opt)
3. Charging connector holder;
4. RFID reader;
5. Emergency Stop button;
6. LED indicators
7. WIFI/4G antenna;
8. Mounting bracket;
9. Air outlet;
10. Charging connector holder;

Explanation of LED indicators behaviors:

- Blue - Standby(The charging equipment can only be used when the blue light lit);
- Red Steady on/Flashing - Fault;
- Green Steady on - Charging in process;
- Green Flashing - Establishing communication;
- Yellow Flashing - System initializing.

Internal view and terminal definition



1. Auxiliary Power Module
2. SPD
3. AC input terminal block. Terminal definition is (①L1;②L2;③L3;④N)
4. Earth Terminal



Fig: AC Surge protection device

Note: The charging equipment will detect the current status of the lightning arrester module in real time. When the lightning protection module is damaged, the display will have an alarm indicating that the lightning protection device is faulty. When repairing and replacing the lightning protection module, the left side cover must be removed first. Then the maintenance person can operate the breaker in the surge protection circuit and replace the lightning protection module! (The red circle in the figure is the lightning protection status indicator. When the indication window indicates green, the lightning protection module is normal; when the indication window indicates red, the lightning protection module has been broken and damaged, and the lightning protection module needs to be replaced.)


2 Packaging List

No.	Items	Qty	Remark
1	Mode charging equipment	1	
2	User manual	1	
3	Certificate of quality	1	
4	User card	2	
5	Mounting bracket	1	Already installed on the rear side of the charging equipment
6	Cable holder	2	
7	Hex head expansion bolt, M8*80/304 stainless steel	12	


3 Installation and wiring

3.1 Wall-mounted


3.1.1 Firstly, according to the specific installation height requirement of the user, determine the installation height of the charging equipment and the installation height of the cable holder. According to the dimensions in the following drawings, drill 4 holes for bracket mounting and 3 holes for cable holder mounting on the wall. Take out the expansion bolts in the packing accessory bag, hammer the expansion bolts into the holes. Remove the nuts and washers for later use.




3.1.2 Loosen the 2 screws at the bottom of the charging equipment that fixes the mounting bracket, keep them properly for later use. Place the mounting bracket onto the bolts just installed and screw the nuts and washers. Take out the cable holder and fix it using the same procedure.




3.1.3 After the mounting bracket and cable holder is fixed, place the charging equipment onto the mounting bracket, with the outward bent part inserted to the slot on the rear side of the charging equipment. Lock the charging equipment onto the bracket at the bottom using the 2 screws. The installation is done.







3.2 Pole-mounted


3.2.1 Open the packaging of the pole, take out the pole and mounting accessories.




3.2.2 The pole must be installed on a hard surface, concrete surface is on a solid ground. Drill holes according recommended, it can also be mounted the requirements marked on the illustration for fixing expansion bolts.




3.2.3 Fix the pole onto the holes with expansion bolts. The input cables shall go into middle area and come out of it from the area below the pole from the bottom cable holder.



3.2.4 Fix the mounting bracket onto the pole.




3.2.5 Position the charger onto the bracket and secure it on the bracket with the 2 screws.



3.3 Wiring

Now prepare for wiring. Use 4 power cables and 1 PE cable, it is suggested to use a 5-core cable(with PE included) for the convenience of using the water-proof cable gland. The live wires shall be at least 16mm², PE shall be greater than 10mm². The PE wire shall be crimped to a M6 size ring terminal. Open the 2 locks at the left side of the upper front cover and open it. Connect the AC input cables into the corresponding terminals through the cable gland on the bottom left side and fasten them(Refer to the Internal view and terminal definition part for wire connection), put the transparent cover on the terminal block for safety purpose. Connect the network cable through the hole in front of the AC input cable gland to the RJ45 socket and fasten the water-proof gland. Turn on the RCBO. Close and lock the upper cover after checking internal wiring and breaker position. The wiring is then finished.

	L1	L2	L3	N	PE
Terminal					
Wire	≥16mm ² ≥AWG5	≥16mm ² ≥AWG5	≥16mm ² ≥AWG5	≥16mm ² ≥AWG5	≥10mm ² ≥AWG7



Notice:

1. Only professional personnel can do the wiring, connect the AC input wires in correct phase order according to the markings on the terminal block.
2. The PE terminal shall be connected to the Earth firmly and reliably!
3. No live work! Turn off the upstream breaker in the distribution panel and the breaker inside the charging equipment before repairing or maintaining.
4. It is recommended to install at least Type A circuit breaker protection at the front of the charger input.

Parameter Configuration 4

RCBO selection at the distribution end:

Rated power P: 40kW

Rated voltage U_e : 400Vac

Operating voltage U : 320~450Vac

Efficiency η : 94%

Power factor PF: $\cos\Phi \geq 0.99$

Rated current $I_e = P / (1.732 * \eta * U_e * \cos\Phi) = 62A$,

recommended RCBO rated current: $\geq 78A = 1.25 * I_e$.

Maximum current $I_{max} = P / (1.732 * \eta * U * \cos\Phi) = 78A$,


recommended RCBO rated current: $\geq 97A = 1.25 * I_{max}$.

5. Do not replace the adapter!


6. Unauthorized use of extension cords is not allowed!

7. Please do not disassemble the unit unless authorized!

After installed and connected, the charging equipment must first be configured according to the actual needs of the user. The parameters are configured through the LCD touch screen. Save the change and exit then the charging equipment can be used normally.



After the system enters standby, click the button marked by the red rectangle in the above figure to enter the system management page, as shown below.



System management page

4.1 System Parameters

System parameters

RFID card PIN code	Charge type
Charge ID	1.APP 2.RFID 3.Plug&Charge
VIN charge setting 0: Disable 1: Enable	Language set
Password set	
Meter address A: B:	DC model
Year Month Day Hour Min Sec	

System parameters page

No.	Parameters	Function description
1	RFID Card PIN CODE	PIN code setting of RFID reader, a 6-digit code, the default setting is 242007. It must be the same with the PIN code of user card. Users can also use other PIN code if they have card writer to change PIN code of user card.
2	Charge ID	Charger ID, suggested to use serial number as charger ID.
3	VIN charge setting	VIN charging settings, set 0 to disable and 1 to enable.
4	Password Set	Password of management page. It's a 4-digit fixed length password, default is "1234".
5	Meter address	DC meter's modbus address(already preset in factory. Settings should not be changed)
6	Time set	System time setting. Format is Y, M, D, H, M, S. The Year setting can only set the last 2 digits, e.g. use 19 for 2019.
7	Charge type	Charging mode setting. 1 is APP; 2 is RFID; 3 is Plug&charge.

No.	Parameters	Function description
8	Language set	Language setting. Currently support Thai-English and Thai-Chinese dual language display.
9	DC model	DC Charger model(Already preset in factory)

After changing parameters, click the "Set" button to save the setting, then click the "Back" button for the setting to take effect.

4.2 Network parameters

Network parameters need to be configured when the charging station needs to be connected to back office server for operation and management. Network parameters include server parameters and charger parameters. Currently the charging equipment only support LAN connection, WiFi/4G is yet to develop.

Network parameters

Server URL1:	
Server URL2:	
Charger IP	WIFI SSID
Subnet mask	WIFI key
Gateway	Authentication key
DNS	4G user name
MAC address	4G password
4G APN	

No.	Parameters	Function description
1	Server URL 1	Server address setting, used to set domain or IP address of back-office server.
2	Server URL 2	Address of backup server. This parameter is not available now, reserved for future use.

No.	Parameters	Function description
3	Charger IP	IP setting of the charging equipment
4	Subnet mask	Subnet mask setting
5	Gateway	Gateway setting
6	DNS	DNS server address
7	MAC address	MAC address
8	4G APN	4G APN setting
9	WIFI SSID	WIFI SSID setting, to set the name of the wireless network to which the charging equipment is to be connected. A reserved function for future use
10	WIFI Key	WiFi password setting. A reserved function for future use
11	Authentication Key	OCPP login authentication setting
12	4G user name	4G user name setting
13	4G password	4G user password setting

6.3 Protection parameters

The protection-related parameters, such as voltage, current, temperature, power, etc.

DC plug protect parameters

DC output overvoltage	V	Charger over temperature	°C
DC output overcurrent	A	Charger derate temperature	°C
Output limit power	kW	Fan starting temperature	°C
DC A output limit power	kW	Insulation resistance	kΩ
DC B output limit power	kW		


No.	Parameters	Function description
1	DC output overvoltage	Over voltage limit setting of DC output
2	DC output overcurrent	Over current limit setting of DC output
3	Output limit power	Power limitation setting of DC output
4	DC A output limit power	Power limitation setting of CCS2-A output
5	DC B output limit power	Power limitation setting of CCS2-B output
6	Charger over temperature	Over temperature limit setting of charging connector
7	Charger derate temperature	Charging connector's temperature at which the charging equipment starts decreasing output power
8	Fan starting temperature	When the internal fan of the charger detects that the internal ring temperature is greater than the set temperature, the charger will start the fan, and when it detects that the temperature is less than the set temperature, the fan will not start.
9	Insulation resistance	The minimum value of insulation resistance

5 Operation Instruction and LCD Introduction

5.1 Charging mode and operation


APP mode:

Initiate or cease charging by scanning QR code using APP or by swiping RFID card. You can also use APP for reservation and payment provided that the back-office server supports such function;



RFID mode:


Initiate or cease charging by swiping RFID card.



RFID mode operation process flow

Plug&Charge:



Charging will start automatically after EV plugged in. If you want to stop the charging, just press the stop icon on the screen.



Plug&Charge mode operation process flow

5.2 LCD interface introduction

The charging equipment is equipped with a 7 inch industrial-grade resistor type touch panel. The display content is as below

	When powered up, the charging equipment will show this display.
	Charging information, which will show the status of the charging equipment, such as standby, charging, fault, etc.

Management

System parameters

Net parameters

Protection parameters

Charging record

Fault details

Charger information

Back

Please enter password

1

2

3

4

5

6

7

8

9

.

0

Return

Enter

Back

System parameters

RFID card PIN code

Charge ID

VIN charge setting 0: Disable 1: Enable

Password set

Meter address A: B:

Year Month Day Hour Min Sec

Factory reset

Reset

Charge type 1.APP 2.RFID 3.Plug&Charge

Language set

DC model

Next

Set

Back

Network parameters

Server URL1: Server URL2:

Charger IP . . .

Subnet mask . . .

Gateway . . .

DNS . . .

MAC address

4G APN

WIFI SSID

WIFI key

Authentication key

4G user name

4G password

Set

Back

Management page, user can set different kinds of parameters here. Password authentication is required when entering each parameter setting page.

Password window. Before entering numeric, please first press the text display field to move the cursor there, then you can type in the 4-digit password. A wrong password will cause no response and action.

System parameters page.

Network parameters page, used to set network related parameters of back-office server and the charging equipment.

DC plug protect parameters

DC output overvoltage V

DC output overcurrent A

Output limit power kW

DC A output limit power kW

DC B output limit power kW

Charger over temperature ℃

Charger derate temperature ℃

Fan starting temperature ℃

Insulation resistance kΩ

Set

Back

Fault details

ID

Time

Detailed description

Page

Clear all fault record

Previous

Next

Back

Charge record

ID

Start time

End time

Electric

Money

Stop reason

Page

Clear all Charge record

Previous

Next

Back

Protection parameters page of DC output, used to set limit value of voltage, current, power, temperature, etc.

Fault record page, user can check history fault record here.

Charging record page.

5.3 Appendix: Fault code

No.	Fault description
1	Emergency stop is pressed!
2	SPD fault!
3	Power module communication fault!
4	Meter communication fault!
5	DC output overvoltage fault!
6	DC output overcurrent fault!
7	Waiting for BMS communication timeout!
8	Insulation detection fault!
9	DC+ Contactor sticking fault!
10	Plug line disconnection fault!
11	Plug head connection over temperature fault!
12	CP short!
13	Door is open!
14	PE cut!
15	PLC fault!
16	Fan working fault!
17	Load Balanc Meter Fault!
18	Ev emergency fault!

Model	EVD-40D
Dimension(mm)	632*300*858(W*D*H)
Weight(kg)	90KG
Display	LCD
Casing material	Stainless steel&acrylic sheet
AC input	
Grid connection	400V, 3 phase 5 wires
Voltage	AC 320~450V
Current	64A
Frequency	50/60Hz
DC output	
Plug type	CCS2
Voltage	DC150~1000V
Current	0-100A
Voltage-stabilizing accuracy	< ±0.5%
Current-stabilizing accuracy	< ±1%
Power factor	≥0.98
Efficiency	≥94%

Ingress protection	IP54
Operating temperature	-25°C~50°C, derate since 50°C
Relative humidity	5%~95%
Altitude	≤2000m, derate for higher than 2000m
Cooling method	Forced air cooling
Remote monitoring	Ethernet/WIFI/4G/485/232
Charging mode	APP/RFIF/Plug&Charge
Standby power	35W
Standards	IEC 62196-3, IEC61851-1, IEC61851-23, ISO15118
Mounting	Wall or Pole
Certificate	CE,CB,RCM,UKCA
Metering accuracy	0.5%
Protection features	
Over /Under voltage t of AC output	Yes
Over voltage of DC output	Yes
Over temperature protection	Derate since 50°C; Stop at 75°C
Emergency stop protection	Yes
Lightning protection	Type II

7.1 Electric diagram




Fig7-1, Main circuit diagram

7.2 Warranty

Warranty period

The warranty period of this product is 3 years. If the contract stipulates otherwise, the contract shall prevail.

For warranty cases during the warranty period, the customer should present the invoice of the purchase of the product to our service team. At the same time, the nameplate on the product should be clearly visible, otherwise the warranty claim might not be accepted.

Warranty condition

We will repair or replace the product free of charge during the warranty period. The defective machine after replacement shall be owned by us, and the customer shall reserve a certain amount of time for us to repair the faulty machine.

Liability exemption

We reserves the right not to accept the warranty claim if the conditions below happen,

- 1.No trademark on the product;
- 2.Warranty period has expired;
- 3.Fault or damage caused by incorrect installation, by installing the device in a not allowed environment, by improper storage or usage, etc.(e.g. too high or too low temperature, moisture or too dry environment, high altitude or unstable voltage/current, etc.)
- 4.Failure or damage caused by the installation, repair, modification or disassembly by unauthorized service personnel;
- 5.Failure or damage caused by using our genuine spare parts;
- 6.Failure or damage caused by accident or human cause (operational error, scratching, handling, bumping, access to inappropriate voltage, etc.), or transport damage;
- 7.Failure or damage caused by force majeure such as natural disasters (such as earthquakes, lightning strikes, fires, etc.);
- 8.Other failures or damages that are not caused by quality problem of the product or its components.

Statement of liability

The copyright of this manual belongs to our company. Any organization or individual may not extract or copy part or all of the contents of this manual without any written permission from us, and may not be reproduced and spread in any form (including materials and publications). We have the final right to interpret this manual. This manual is subject to change without prior notice. For more information, please contact us.

7.3 Contact

Company Name: Shenzhen ATESS Power Technology Co.,Ltd

Address: GROWATT-ATESS Industrial Park, No.23 Zhulongtian Road, Shuitian Community, Shiyan Street, Baoan District, Shenzhen

Website: www.atesspower.com

Service line:+8675529988492

E-mail:info@atesspower.com