



# SHENZHEN ATESS POWER TECHNOLOGY CO.,LTD

GROWATT-ATESS Industrial Park, No.23 Zhulongtian Road, Shuitian Community, Shiyan Street, Baoan District, Shenzhen

Tel: +86 755 2998 8492 Web: www.atesspower.com Email: info@atesspower.com Revised date: 2025-10-27



# **ATESS VoltageStack Battery**

Energy Storage System User Manual

# **Foreword**

# **Legal Notices**

The copyright of this material belongs to the company. No unit or individual may extract, copy or translate in any way without the written permission of the copyright owner.

Infringement must be investigated.

This manual does not grant the reader any license or right to use any of the marks appearing in this manual without the prior written consent of the company or third party trademark or trade name owner.

This product complies with the design requirements for environmental protection and personal safety. The storage, use and disposal of the product shall be in accordance with the product manual, relevant contract or relevant national laws and regulations.

# Manual description

The VoltageStack Battery series of energy storage systems provide energy storage for PV users. During the day, the excess power of PV power generation can be stored in the battery. At night or when needed, the stored electrical energy can be used to supply power to the electrical equipment, which can improve the efficiency of PV power generation, peak filling and valley filling, and emergency power backup.

This user manual system details the basic structure, parameters, basic procedures and methods of installation and operation and maintenance of the equipment.

# **Contents**

1 Summarize 1.1 Symbol Introduction 1.2 Special Instructions 2 Safety Precautions 2.1 General Safety Considerations 2.2 Electrical Safety 2.3 Battery Safety 2.4 Wiring Requirements 2.5 Mechanical Safety 3 System Introductions 3.1 Introduction 3.2 Battery Module 3.3 BPU 3.4 VoltageStack Battery 4 Operating Environment 5 Transportation and **Storage Requirements** 5.1 Transportation and Storage 5.2 Transporting

6 Device Installation and Configuration 6.6 Electrical connections 6.7 Post-installation check 7 Maintenance 8 common **Troubleshooting** 

7.1 Safety instructions for inspection and maintenance 7.2 Tools to be used during maintenance 7.3 System inspection table 7.4 System inspection and maintenance 7.5 VoltageStack Battery Upper Computer Interface ■ 7.6 Liability exemption 8.1 Fault and Abnormal State Processing 8.2 Battery Fault Table 8.3 Fault phenomenon and troubleshooting methods 9 Annex

6.1 Installation preparation

6.3 Unpacking inspection

6.4 Preparation before installation 6.5 Battery module installation

6.9 function operation and testing

6.2 Tool Preparation

6.8 Power on

Summarize

# Safety Precautions 2

## 1.1 Symbol Introduction

• BCU: Battery Control Unit

BMU: Battery Management Unit

BMS: Battery Management System

• ESS: Energy Storage System

BPU: Battery Power Unit

#### VoltageStack Battery: Energy storage VoltageStack Battery



This sign indicates safety hazard during operation. Failure to follow such warning information, it will directly lead to serious personal injury or death



This sign indicates a potential hazard during operation. Failure to follow such warnings may result in personal injury or death



This sign indicates a potential hazard during operation. Failure to follow such warnings may result in personal injury or death

# 1.2 Special Instructions

This manual covers the installation and use of the battery energy storage system product.

Please read this manual before installation.

The energy storage system must be commissioned and maintained by the engineers who had been trained, otherwise it may lead to injury and equipment failure. The resulting equipment damage is not covered by the warranty.

The pictures configured in the manual just for illustrative purposes. If it is not match the actual product, please refer to the actual product.

# 2.1 General Safety Considerations

- The product should be used under the specified working environment (voltage, current, temperature, humidity, etc.), otherwise the product may malfunction. The resulting product malfunction or component damage is not covered by the product warranty.
- Operators should comply with local regulations. The safety precautions in the manual are only intended to supplement local safety regulations.
- It is strictly forbidden to wear items such as watches, Bracelets, bangles, rings, etc. that are easily conductive during operation.
- Special insulated tools must be used during operation.
- The torque wrench should be used to fix the screw and double check the screw with the red and black logo. After the installer confirms that the screws are tightened, please mark black on the screws; the inspector confirms that the screws are tightened, please mark red on the screws.
- Installation or maintenance operations must follow the steps in the specification and manual.
- If you need to touch any conductor surface or terminal, use a meter to measure the voltage at the contact point before contact, and verify that the contact point is voltage-free or voltage within the predicted range.
- If the cable is stored in an environment below 0°C, the cable must be stored in room temperature environment (25±5°C) for more than 24 hours before the cable is used.
- After the product is installed, routine inspection and maintenance is necessary, and replace the faulty components in time to ensure the safe operation of the product.

# 2.2 Electrical Safety

#### **Grounding Requirements**

- When installing the product, the protective grounding wire must be installed first; when the product is removed, the protective grounding wire must be removed at the end.
- Before operating the product, check the product to ensure that the product is reliably grounded ( $\leq 4\Omega$ ). Not well grounding of the equipment may result in personal injury and equipment damage.

# AC and DC Operation Requirements

#### DANGER

The supply voltage of the energy storage system is dangerous (>60V). Direct contact the system or indirect contact the system through wet objects can be dangerous.



Incorrect operation may result in accidents such as fire or electric shock.

Before the product is electrically connected, the front-end protection switch of the product must be disconnected.

Before connecting AC power, must ensure that the electrical connections of the equipment has done.

Before connecting the load cable or battery cable, must confirm the polarity of the cables and terminals is correct, prevent reverse connection.

#### **Anti-liquid Requirement**

The installation location of product should be away from the liquid area, prevent liquid from entering the product and causing short circuit, and to ensure that there is no condensation in the room and product.

When liquid enter the room or product, turn off the power immediately and notify the manager.

# 2.3 Battery Safety

#### **Basic Requirements**

#### DANGER

Wear protective tools such as helmet, insulated shoes, gloves, etc. before installation, maintenance or operation the product.

- Pay attention to the safety protection of the battery to avoid collision and falling, when installing, maintaining, and operation the product.
- The wiring circuit should be kept disconnected during installation, maintenance.
- Tighten the cable according to the torque in the manual, to prevent poor contact and cause heat or even damage the product.
- It is strictly forbidden to damage the battery explosion-proof valve or exhaust valve, otherwise it will cause electrolyte leakage.
- Make sure that the installed battery is the same model.
- Always dispose of used batteries in accordance with local regulations.
- The storage environment of the battery should be free from direct sunlight or rain, dry and well ventilated, and the surrounding environment is clean and away from fire.

#### DANGER

> Do not allow anyone or animals to swallow any parts of the battery or the contents of the battery.



- > Do not pierce the battery with nails or other sharp objects.
- > Do not put the battery into fire or expose it to high temperatures for a long time, as this may cause a fire.
- > Lithium batteries are not allowed to be charged at low temperatures (<0°C).
- $\,>\,$  If the model of the replacement battery is incorrect, there is a safety hazard.

#### WARNING

- > Do not immerse the battery in water. When it is not in use, it should be placed in a cool and dry environment.
- > Do not use or leave the battery near hot and high temperature sources such as fire, heaters, etc.



- > Forbidden to reverse the positive and negative terminals of the battery during use.
- > Forbidden to connect the positive and negative terminals of the battery directly with metal, resulting in short circuit of the battery.
- > Forbidden to transport or store batteries with metals such as hairpins, necklaces, etc.
- > Forbidden to strike or throw, trample or bend the battery.

#### **Battery Short Circuit Protection**

#### **DANGER**

The battery cell and battery system (module, pack, cabinet, system) circuit must not have any form of short-circuited, otherwise short-circuit may cause fire and may cause personal injury.

If possible, disconnect the battery connection before operation.

#### Battery leakage electrolyte protection

#### CAUTION



Excessive battery temperature can cause battery deformation, damage, and electrolyte spillage.

When the electrolyte of the lithium battery is found to leak, the skin and eyes should be prevented from directly contacting the electrolyte. If there is contact, use plenty of water to clean the area and contact doctor for help.

#### Charging

- Charging current shall not exceed the maximum charging current in the specifications. Otherwise it would cause the problem in charge and discharge performance, mechanical performance and safety performance.
- Charging voltage shall not exceed the maximum charging current in the specifications. Otherwise it would cause the problem in charge and discharge performance, mechanical performance and safety performance.
- Batteries must be charged within the ambient temperature range of 20°C ~30°C.
- Forbidding reverse charge. Battery should be connected correctly. It is strictly prohibited to reverse charge. Otherwise it will cause the battery scrap and produce safe hidden trouble.

#### Discharge

- Discharge current shall not exceed the maximum charging current in the specifications. Otherwise it would cause dramatically capacity loss and overheating.
- $\bullet$  Batteries must be discharge within the ambient temperature range of 20°C ~30°C.
- Forbidding over-discharge. Battery management system should be installed to prevent over discharge during the usage. Over discharge will cause the battery scrap and produce safety hazard. It is necessary to state that for the battery not used for a long time, it may over discharge due to the self-discharge characteristics. To prevent the occurrence of over discharge, the battery should be regularly charge and the voltage should be remained above 3.2 V.

# 2.4 Wiring Requirements

- Cable used in high temperature environment, will cause the insulation aged or damaged. Thus the cable should be kept at a sufficient distance from the DC bus bar, splitter, and fuse.
- Signal cable and power cable should be routed separately (≥60cm).
- User-supplied cables should meet the VW-1 test requirements.
- No cable is allowed to pass behind the air outlet of the power module in the cabinet.

# 2.5 Mechanical Safety

#### Removing Heavy Objects Safely

- When carrying heavy objects, be prepared for weight bearing to avoid being crushed or sprained by heavy objects.
- Generally, it's forbidden to transport the heavy product by one person.
- Wear protective gloves when handling product by hand to prevent your hands from being cut by sharp corners.
- When transporting with a forklift, the forklift fork should in the middle position to ensure symmetry. Do not excessively bump and tilt during handling. The angle of the left and right tilt of the equipment during loading or unloading should not exceed 15°. In order to avoid tipping over, please fasten the product to the forklift with a rope before moving, and take care when moving. Be careful to move the product to avoid damage caused by any impact or drop.

# System Introductions 3

#### 3.1 Introduction

The VoltageStack Battery Series energy storage system uses a lithium-iron phosphate battery equipped with battery management system (BMS) designed for industrial and commercial energy storage applications. During the day, the excess PV power can be stored in the battery. At night or when needed, the stored electrical energy can be supplied to the electrical equipment, which can improve the efficiency of PV power generation, peak-shaving, and emergency power backup.

#### Comply with international standards and certifications

Lithium batteries have passed CE, UN38.3 and other certifications.

# High reliability system

Adopt high-performance processor and ensure the stable operation of the system based on the three-layer management mode.

Real-time monitoring of system conditions, providing short-circuit protection, reverse connection protection, high-voltage protection, low-voltage protection, charging over-current protection, discharge over-current protection, over-charge protection, over-discharge protection, high-temperature protection, low-temperature protection, cell balancing and other functions.

#### Powerful communication features

Configure a variety of communication interfaces: USB, RS-485, WiFi, 4G (optional), CAN, you can know the battery working status at any time through the host computer

# 3.2 Battery Module

#### 3.2.1 Battery module front panel schematic




Figure-1 Battery module panel appearance

Power Terminal +/-

To connect battery series power cables

Battery Temperature Collection Port

Port for collecting the temperature of the battery cell in the battery box.

Battery Voltage Collection Port

The voltage and total voltage of each cell in the battery box are collected

CPU Download Port

Used to download or update CPU programs.

Fan Power Port


Battery box fan driver input port.

Battery Pack Communication Port

To connect battery series communication lines.

## 3.2.2 Battery module dimension








Figure-2 Battery module dimension

# 3.2.3 Battery module parameters

No.	Item	Parameters	Remark
1	Nominal voltage/capacity	51.2V/100Ah	165
2	Weight	≤48Kg	Contains the accessories
3	Size	D630*W428*H168mm	Tolerance ±0.5mm
4	Insulation resistance	≥1000 Ω/V	2500V (DC)
5	Interal resistance	≤8m Ω	

Figure-3 Battery module parameters

#### 3.2.4 Battery module standard configuration

Part name		Specification					
ESS-BM-51.2-100R	I	Jse lithium-iron phosphate battery, apacity 14.3KWh, including BMU, fuse.					
Power Termina+/-	DC1500	V/100A	4			M8/8N·M	
Power communication terminal	I			both se tween batte			
		No.	CN5	CN6			
		1	CAN_H	CAN_H			
		2	CAN_L	CAN_L			
		3	GND	GND			
		4	+24V	+24V			
		5	GND-A	GND-A			
		6	+24V-A	+24V-A			
		7	CANGND	CANGND			
		8	NC	NC			
		9	GND	GND			
		10	+24V	+24V			
		11	GND-A	GND-A			
		12	+24V-A	+24V-A			

#### 3.3 BPU

#### 3.3.1 BPU front panel schematic




Figure-4 BPU front panel schematic

Power Switch

Switch the battery system's (high voltage box and high voltage DC power)ON/OFF.

Power Terminal +/-

To connect battery series power cables(Battery cluster). Terminals marked BAT+/BAT- are connected to the positive and negative terminals of the first battery pack and the last battery pack respectively.

Communication Port 1

To connect the first battery in series communication lines.

Communication Port 2/3

To connect high voltage box series communication lines.

Communication Port 4

Reserved debugging port.

External Power +/-

To connect HPS/PCS or DC Cabinet(When having three or more parallel systems).


**USB Port** 

Used to upgrade the BCU board code.

Run/ Alarm Light

Indicates the normal running or cannot run properly of the system.

#### 3.3.2 BPU dimensions








Figure-5 BPU dimensions

## 3.3.3 BPU standard configuration

Part name		specification						
BPU body	moth modu	It contains control board or three-layer motherboard, power board, power conversion module, fuse, relay, LED power indicator with red and green, and is made of insulated metal casing.						
Input/output terminal	DC15	DC1500V/100A						
Power communication		des CAN, I	RS485, 24V po	wersupp	ly;			
terminal	No.	сом1	сом2/сом3	сом4	сом5			
	1	-24V	-24V	24V-	Dry1-2			
	2	+24V	+24V	+24V	Dry1-1			
	3	NC	485_A	RX_232	NC			
	4	NC	485_B	TX_232	NC			
	5	CAN1_H	CAN2_H	Relay4	D14-			
	6	CAN1_L	CAN2_L	Relay5	RGND			
	7	CANGND	EX485_A	Relay6	DI3-			
	8	NC	EX485_B	EGND	RGND			

# 3.4 VoltageStack Battery

#### 3.4.1 VoltageStack Battery dimensions

For each layer removed from the stack, the overall height decreases by 165 mm.




Figure-6 VoltageStack Battery size

## 3.4.2 VoltageStack Battery detailed layout




Figure-7 VoltageStack Battery detailed layout

# 3.4.3 VoltageStack Battery configuration

The main components of the BC series energy storage VoltageStack Battery system are shown in Table-1 below.

No.	Materials	Quantity	Unit
1	Product inspection report	1	PCS
2	Product certification	1	PCS
3	Battery Pack	12	PCS
4	High Voltage Box	1	PCS
5	Base	1	PCS
6	Series Copper Busbar	11	PCS
7	Series Cable	2	PCS

No.	Materials	Quantity	Unit
8	Battery Communication Cable	10	PCS
9	Battery to HV Box Communication Cable	1	PCS
10	HV Box to HV Box Communication Cable	1	PCS
11	Enclosure Fixing Connector	52	PCS

Table-1Main components of BC battery energy storage system

104

30

PCS


PCS

M5×12 Cross Recessed Hex Head Combination Screw

M6×14 Cross Recessed Hex Head Combination Screw

#### Parts and Accessories List

13



**Note:** In the table 2, N indicates the number of parallel battery systems. For example, N=2 indicates a two-parallel battery systems, it's made up of two VoltageStack Battery. Some materials need to be multiplied by 2.

# Operating Environment 4

Battery operating environment requirements are as follows

Working temperature: 20 ° C - 30 ° C

Relative humidity: 5% - 95%, no condensation

Altitude: ≤2000m

On-site environment: keep away from heat sources, avoid direct sunlight, no corrosive gas, no explosive gas, no gas that destroys insulation, Conductive dust without damaging insulation.

# **5** Transportation and storage requirements

# 5.1 Transportation and storage

High voltage box and battery pack should be transported separately. Pay attention to the dentification on the packing box when transporting and storing the product. The storage ocation should be:

- No corrosive gas around.
- No excessive humidity and high temperature source.
- Non-dusty environment.
- Meet fire protection requirements.
- It is suggested that is stored in the environment temperature -10° C~30° C, clean, dry and ventilated indoor environment. Avoid contact with corrosive materials and stay away from fire and heat sources.
- Environmental humidity<70%

# During transportation, handling and installation:

- Avoid collision of parts or parts with objects such as doors, walls, and shelves.
- Wearing neat gloves, it is strictly forbidden to touch parts with bare hands, sweaty or dirty gloves.

# 5.2 Transporting

User can lift the whole package box from the bottom by means of a forklift and can transport it independently, as shown in figure-8.



Figure-8 Forklift use reference diagram

# **6** Device installation and configuration

# 6.1 Installation preparation

## 6.1.1 Safety regulations

Only those who have received training in the power system and have a good knowledge of the power system are allowed to install the device. Always follow local safety regulations and the safety requirements listed below during installation.


Before installing or removing the device, make sure that the power system is not powered and that the battery device is turned off. Distribution cable routing should be reasonable and protective, to avoid touching these cables when operating the power supply.


# 6.1.2 Check the operating environment

The operating environment shall comply with the requirements described in Chapter 4, "Operating Environment" . If it does not, it shall be rectified and the operating environment shall be re-examined.

#### 6.1.3 Installation notes

- 1. Place the product indoors in a cool, dry, and well-ventilated environment.
- 2. Ensure the product is placed on a relatively flat surface.
- 3. Keep a minimum clearance of 0.5 m from both the left and right sides to the wall.
- 4. Maintain a minimum clearance of  $0.3\ m$  between the top of the product and the ceiling.
- 5. Maintain a minimum clearance of 0.03 m between the back of the product and the wall
- 6. For long-term placement, turn the caster adjustment gears clockwise to ensure the casters are firmly supported on the ground.





# 6.2 Tool Preparation

No.	Name	Quantity	Model	Remark	Legend
1	Wrench	4	12-inch	Plastic handle (with scale)	
2	Warning band	10	Rubber road cone 70CM reflective	High 70CM bottom 44×44CM	À
3	Helmet	6	3 M	Glass reinforced plastics conventional red	
4	Gloves (DC insulation)	4	Thickened anti-electric		*
5	Insulated shoes	6	3M		
6	Multimeter	2	1kV range		
7	Clamp ammeter	2	2kA range		
8	Sleeve	2	Interchangeable		200000000
9	Tape measure	1	100M		•
10	Forklift	2	Interchangeable		
11	Electric drill	2	Interchangeable		770
12	Insulation resistance meter	1	Interchangeable		

Table-2 Installation tool table

# 6.3 Unpacking inspection

Before the battery module is ready for installation, an unpacking check is required, mainly check the following:

- Check whether the number of items in the packing list matches the actual items
- Check whether the documents and accessories are complete
- Check whether the battery module case is deformed, painted or loose

Take photos before and after unpack the packing. If the number of items is the same as the packing list, sign the confirmation packing list with the customer. If find the equipment is damaged or corroded during the unpacking inspection process, it should be promptly reported

# 6.4 Preparation before installation

- Make sure all the BPU switches are in the OFF state
- Cut off all relevant equipment power supply

# 6.5 Battery module installation

Before install the battery module check that the VoltageStack Battery is properly installed and grounded.

- 1). Take the battery module out of the box.
- 2). The high voltage box should be installed on top of the stacked battery packs
- 3). The address of the battery box is set according to the dial switch (CN7) on the BMU board, as shown in Figure-9, the dial switch is set according to the binary address, from 1 to 5 switch represents high to low, for example: only open the first switch, close 2 to 5 switch, the set address is 16.






Figure-9 Diagram of battery pack and BMU board


4) Place the battery case in the corresponding position of the battery holder according to Figure-10, and fix the battery case to the battery holder with the matching M6 screw.



- 1. M5\*12 Screw
- 2. Box fixing connector

- 1. M5\*12 Screw
- 2. Box fixing connector
- 3. Terminal plastic cover
- 4. M6\*16 Screw
- 5. Series connection wire





- 1. M5\*12 Screw
- 2. Box fixing connector
- 3. Terminal plastic cover
- 4. M6\*16 Screw
- 5. Series connection wire
- 6. Series terminal block
- 7. End connection wire between battery packs

Figure-10 Installation diagram of the battery module(picture is for reference only)

#### Precautions:

Wear protective shoes when assembling energy storage systems

- Staff long-sleeved shirt. It is forbidden to wear sleeveless shirts and it is forbidden to roll up the sleeves
- All personnel involved in the work wear appropriate gloves
- The battery module is about 48kg depending on the model. It is forbidden to move by one person to prevent personal injury
- Each battery cluster is 2 columns, 6layers. After installation, check the installation order and position of each cluster of battery modules. It is forbidden to mix different clusters of battery modules
- The torque of the battery module locking bolt is 12Nm

#### 6.6 Electrical connections

## 6.6.1 Connecting ground

Grounding resistance needs to be less than  $1\Omega$ ;

#### 6.6.2 Battery module DC cable/copper bar

1). Take out the matching series DC cable/copper bar as shown in Figure-11 and separate the series DC cables according to the cable labels.





Figure-11 Schematic diagram of the series DC cable/copper bar (picture is for reference only)

- 2). According to the wiring position of Figure-12, connect the No. 3 series DC copper bar to each cluster first, then connect the No. 1 serial DC cable, then connect the No. 4 serial DC copper bar, and finally connect the No. 2 cable.
- 3). Connect from bottom to top during wiring to prevent misconnection and shorting.



Figur-12 Battery cluster DC cable wiring diagram (picture is for reference only)

NO.	Name	length(mm)	Quantity
1	Series DC cable 1	650	1
2	Series DC cable 2	750	1
3	Battery Serial copper bar	219	10
4	Copper busbar from HV box positive pole to battery PACK positive pole	220.79	1

Series DC Cable

#### Demonstration of installation examples:

- Each battery cluster is 2 columns, 6 layers. When connecting DC cables, connect the battery module of each column in series, and measure the voltage of each column of the battery module with a multimeter. If there is no abnormality, then string the two columns of battery modules.
- After all the batteries in the cluster are connected in series, use the insulation meter to measure the insulation level between the positive electrode of the battery cluster (the positive electrode of the battery module 1) and the VoltageStack Battery, and the insulation level between the negative electrode of the battery cluster (the negative electrode of the battery module 11) and the VoltageStack Battery. The insulation should be more than  $100\Omega/V$ .
- After the DC cable is connected, tap the cable plug connector with a rubber hammer to ensure that the cable is securely installed.

#### 6.6.3 Battery module communication cable wiring

1) Take out the matching battery module communication line as shown in Figure-13 and eparate the communication line according to the battery module communication line label.



Figure-13 Battery module communication cable diagram (picture is for reference only)

2) According to the wiring position shown in Figure-14, each cluster is connected to the battery module communication line in the S-shape from the lower right corner.




Figure-14 Battery cluster communication cable wiring diagram (picture is for reference only)

NO.	Name	Length(mm)	Quantity
1	BPU to battery pack communication line	850	1
2	Batteies series communication line	195	10

Battery pack communication line

#### 6.6.4 BPU wiring instructions

After the power line and communication line inside the VoltageStack Battery are connected, install the inverter according to the inverter manual, and connect the battery input end of the inverter to the DC output end of the battery BPU, and output the BPU COM2. The line is connected to the CAN communication input port of the inverter.

Note:When three units are paralleling (include three), COM 2 port of BPU-1 connect to DC cabinet, one unit or two units are paralleling, COM 2 port of BPU-1 connect to display.




Figure-15 Schematic diagram of the BPU wiring for reference

#### 6.7 Post-installation check

After the installation of the energy storage system is completed, post-installation inspection is required:

- The VoltageStack Battery and the battery module are aligned with the mounting holes, the screws are tightened, and the torque meets the requirements (12Nm)
- The battery module number and installation location are the same

# Precautions:

- Check whether each communication cable interface is secure and the single small wire harness is loose before installation
- $\bullet$  Check the screws of each interface after installation to confirm whether it is tightened

# 6.8 Power on

## 6.8.1 System power supply instructions

Inside the container system, the power supply mode of the system is always determined by the total voltage of the battery module, regardless of the standalone or parallel system

## 6.8.2 System power-on instructions




Figure-16 BPU front interface

- 1) Before powering on, please check whether the battery power line and communication line are consistent with the instructions in the installation manual.
- 2) After confirming that there is no problem with the wiring, you can first dial the POWER SW, close the DC power switch, and the system is powered on.

# 6.9 Function operation and testing

No.	Status	Description
1	Mode green light: 3s flashing cycle - slow flashing	System standby
'	Alarm red light: often off	Trouble free
	Mode green light: 1s flashing cycle	charging
2	Alarm red light: 1s flashing cycle	First level alarm
	Mode green light: 2s consecutive flashes	Discharge state
3	Alarm red light: 2s consecutive flashes	Secondary fault
4	Mode green light: always BCight	system error
4	Alarm red light: 3s flashes in succession	Tertiary fault

BPU LED indicator description

**Special note:** When wiring the COM port of the BPU, please pay attention to the line mark on the connection line, beware of incorrect wiring

- End of installation -

# 7 Maintenance

# 7.1 Safety instructions for inspection and maintenance

- 1) There is potential danger in the battery, so proper protective measures must be taken during operation and maintenance.
- 2) The battery must be operated with the correct tools and protective equipment.
- 3) Battery maintenance must be carried out by people with battery expertise and safety training.
- 4) The operator may be injured by chemicals, electric shock or electric arc during operation. Although each human body's response to DC and AC current is different, DC or AC current with voltage higher than 50V are equally serious to human body, so the operator must take a conservative posture in operation to avoid the current injury.
- 5) When operating batteries and selecting personal protective equipment, customers and their employees must take the above risks into account to prevent accidental short circuit, arc, explosion or thermal runaway.
- 6) In case of any abnormal problems, please contact the after-sales technical personnel in time.
- 7) If you need to open the cover for maintenance (such as forced charge and discharge of cell, replace board, etc.), please carry out with the authorization of our engineer.

# 7.2 Tools to be used during maintenance

Prepare tools to be used during maintenance before operation.

Cell phone that can take photos
Multimeter
Thermometer
Pen and paper
Spanner, screwdriver etc
Thermalimager

# 7.3 System inspection table

29

When carrying out inspection, maintenance and inspection work, it is necessary to conduct inspection one by one according to the table, and describe the corresponding problems of the faulty items.


 $Please\ refer to\ Appenx\ - System\ inspection\ and\ Maintenance\ Checklist\ in\ Capture\ 9.$ 

# 7.4 System inspection and maintenance record

#### 7.4.1 Main page parameters and fault parameter records

Date	Serial number	Location	Station name	Status
Vtotal	Location Vmax	Cell Vmax	Location Vmin	Cell Vmin
Itotal	Location Tmax	Cell Tmax	Location Tmin	Cell Tmin
SOC	Cell Vdiff ∆U	Cell Tdiff ∆T		

At the same time of data recording, it is also necessary to take photos of the actual situation for retention. The interface photos are as follow:



7.4.2 The following three tables are battery standby, charging and discharging. You can select one of them to record according to the actual situation during the inspection.

(1) Observe the minimum and maximum values of the battery voltage, and record the module position in the VoltageStack Battery standby state:

	Cell voltage	Module No.	VoltageStack Batterv No.	Serial No. of battery cluster
Max. cell voltage			Battery No.	battery ctaster
Min. cell voltage				

(2) Observe the minimum and maximum values of battery voltage, and record the module position when charging. The charging power is 100% of the rated capacity of the inverter (if the HPS is 5kW, the charging power is set to 5kW), please ensure that the HPS can be charged through a constant current.

	Cell voltage	MadulaNa	VoltageStack	Serial No. of
	Cell vollage	Module No.	Battery No.	battery cluster
Max. cell voltage				
Min. cell voltage				

(3) Observe the minimum and maximum values of the battery, and record the module position when discharging. The discharge power is 100% of the rated capacity of the inverter (if the HPS is 5kW, the discharge power is set to 5kW), please ensure that the HPS can discharge through a constant current.

	Cell voltage	Module No.	VoltageStack Battery No.	Serial No. of battery cluster
Max. cell voltage				
Min. cell voltage				


#### Note:

- 1. It is recommended to run the charge / discharge test at a constant current for at least 3-5 minutes, and then record on paper.
- 2. "Field test battery" is the most important debugging procedure.
- 3. If the battery voltage is found to be too high or too low, the battery needs to be charged or discharged under the guidance of the ATESS engineer.
- 4. If the temperature is abnormal, the temperature sensor needs to be replaced under the guidance of ATESS engineer.
- 5. If there is no available power supply to charge the battery for more than 2 weeks, it is recommended to charge the battery forcibly.

# 7.5 VoltageStack Battery Upper Computer Interface

Upper Computer Interface and Device Communication Connection Instructions: Screen scaling and layout recommendation: 100%

- (1) COM SET
- (2) COM NAME
- (3) BAUD: 115200 bit/s
- (4) Device Address: BCU Address
- (5) Setting
- (6) Click Connect



# 7.5.1 DATA Page(Only the master unit has data; the DATA page parameters are system battery data)

The host device(default BCU address 1) has data, and the DATA page parameter is used to view system battery data information.



# 7.5.2 HOME Page



# System Parameter

Num	Data Name	Value	Modify Ranges
1	HostID	-(View based on actual battery group)	-
2	Remaining Capacity	50(Rated capacity * SOC * 0.01)	-
3	SOH	100(The state of health of the battery)	-
4	State Keep	0	-
5	Battery Status	0: Wait 1: Fault 2: ForbidCharge 3: ForbidDischarge 4: Charging 5: Discharging	-
6	System Status	0: Wait 1: Charging 2: Discharging 3: Fault	-
7	Total Voltage(V)	-(Total Voltage of the battery)	-
8 Total Current (A) -(Total Current of the batte		-(Total Current of the battery)	-
9	Charge Current Command(A)	50(Maximum charging current limit of the battery cluster)	-
10	Discharge Current Command(A)	50(Maximum discharge current limit of battery cluster)	-

Num	Data Name	Value	Modify Ranges
11	Charge Cycles	-	-
12	Number of Shutdowns	0(Cumulative shutdown times due to level 3 or above faults)	-
13	Total Voltage Low(close)	0	-
14	High Voltage Relay Status	1(Relay status (connect, disconnect)	-
15	Relay FeedBack State	-	_
16	Online Battery Group	-(The number of battery clusters operating normally in the system)	-
17	Min Online Battery Group	-(Minimum number of battery clusters required for normal operation of the system)	1~15
18	Battery Group	-(The total number of battery clusters in the system)	1~15
19	Number of Pack	11(Number of BMUs in a single battery cluster)	1~15
20	Number of Cells	16(Number of cells collected by a single BMU)	1~42
21	Current Manual Control	0 (manually modify the charging demand current, the maximum charging current no longer checks the charging current table)	0~310
22	soc	50	0~100
23	Rated Capacity	100(Battery type related data verification)	0~100
24	SOC Lower Limit	10(Discharge SOC lower limit parameter)	0~20
25	SOC Upper Limit	100(charging SOC upper limit parameter)	90~100
26	485A Address	1	-
27	485 SetFlag	0	0~1
28	BCU System Number	The BCU system numbers for the same system must be the same; however, the system numbers for different battery systems under the same collector cannot be the same. For example: Battery System 1 (all BCU systems are numbered as 1)	1~30
29	Battery Type	(0:RP100 1:ETC100 2:RP100H 3:TN100)	0~3
30	SOC Mode Enable	0 (0: SOC is calculated based on the number of charge and discharge cycles 1: SOC is determined basedonthe actual charge and discharge capacity)	0~1

# **Battery Parameters**

Num	Data Name	Value	Modify Ranges
1	Max Temp / Location -(Location: Max Temp. PACK Num)		-
2	Min Temp / Location -(Location: Min Temp. PACK Num)		-
3	Max Voltage /Location -(Location: Max Voltage PACK Num-Cell Num)		-
4	Max Voltage /Location	-(Location: Min Voltage PACK Num-Cell Num)	-

# Capacity/Power Parameters

Num	Data Name	Value	Modify Ranges
1	Rated Energy	56	-
2	Charging Capacity(kWh)	0(Total charging capacity of battery cluster)	-
3	Discharging Capacity (kWh)	0(Total discharge capacity of battery cluster)	-
4	Charging Energy(kWh)	0(Total charging Energy of battery cluster)	-
5	Discharging Energy (kWh)	0(Total discharge Energy of battery cluster)	-
6	Remaining Energy (kWh)	0(Remaining Energy of battery cluster)	-
7	Electricity/Energy Reset	-(Location: Min Voltage PACK Num-Cell Num)	0~1

# Fault / Protection Parameters

Num	Data Name	Value	Modify Ranges
		-The insulation value of the system operation. This value must be observed to trigger an insulation fault. It cannot be -1 (-1 means that the insulation module is not connected)	-
2	CAN1 Error	00 (If a communication failure between BMU and BCU is reported, this parameter needs to be checked. The value indicates that the communication with the BMU address has timed out.)	-
3	ActBal CurFault BMU Num	0	-
4	Total Diff Voltage	5(Total pressure difference fault value of multiple parallel battery packs)	0~10
5	Insu Mode Enable	1(0: Insulation faults are detected according to normal logic. 1: Insulation faults are detected based on the inverter status and communication status)	0~1

Num	Data Name	Value	Modify Ranges
6	Voltage Protection time(100ms)	20(voltage fault duration judgment time)	0~60
7	Current Protection time(100ms)	10(Current fault duration judgment time)	0~60
8	Temp Protection time(100ms)	40(temperature fault duration judgment time)	0~60
9	Fault Message Clear Flag	0	0~1
10	Insu Fault Value(KΩ)	10 (minimum insulation value less than this parameter will trigger insulation fault)	0~1000
11	Insu Protect Time(min)	11(Insulation fault protection time)	0~1440

# **Equipment Information**

Num	Data Name	Value	Modify Ranges
1	Serial Number	-(BCU serial number)	'0'~'9'; 'A'~'Z' 'a'~'z'
2	Hardware Version	-(BCU Hardware number)	'0'~'9'; 'A'~'Z' 'a'~'z'
3	Software Version	-(BCU Software number)	'0'~'9'; 'A'~'Z' 'a'~'z'
4	BCU time	-(BCU Time)	Year:2025~2099 Month:1~12 Day:1~31 Hour:0~23 Minute:0~59 Second:0~59

## 7.5.3 SETTINGS Page



# Voltage

Num	Data Name	Value	Modify Ranges
0	Cell Voltage High 3(V)	3.65	3~4.5
1	Cell Voltage High 2(V)	3.6	3~4.5
2	Cell Voltage High 1(V)	3.58	3~4.5
3	Cell Voltage Low 3(V)	2.7	2~3.3
4	Cell Voltage Low 2(V)	2.8	2~3.3
5	Cell Voltage Low 1(V)	2.87	2~3.3
6	Cell Voltage Diff High 3(V)	0.5	0.1~0.5
7	Cell Voltage Diff High 2(V)	0.3	0.1~0.5
8	Cell Voltage Diff High 1(V)	0.25	0.1~0.5
9	Full Charge Voltage(V)	3.55(The maximum voltage value of the battery cluster when it triggers the charging prohibition state during charging)	3.2~4.5

Num	Data Name	Value	Modify Ranges
10	Nominal Voltage(V)	3.2	2.5~4
11	Full Discharge Voltage(V)	2.9(The minimum voltage value at which the battery cluster triggers the discharge-inhibited state during discharge)	2~3.2
12	Volt Ratio	1	1~5
13	Cell Voltage Recovery(V)	0.1	0.1~0.5
14	Cell Volt Diff Recovery(V)	0.1	0.1~0.5
15	Balance Mode	O(Passive balancing system, balancing mode set to 0, Active balancing system: balancing mode set to 1 (active and passive balancing switch)	-1~1

#### Current

Num	Data Name	Value	Modify Ranges
0	Current Sensor Model(A)	300	-
1	Charge Max Current(A)	100	100~900
2	Discharge Max Current(A)	-100	(-900)~(-100)
3	Charge Current High 3(A)	115	1~900
4	Charge Current High 2(A)	110	1~900
5	Charge Current High 1(A)	105	1~900
6	Charge Start Current(A)	3	1~20
7	Discharge Start Current(A)	-3	(-20)~(-1)
8	Start Current Deviation(A)	2	1~20
9	Discharge Current High 3(A)	-115	(-900)~(-1)
10	Discharge Current High 2(A)	-110	(-900)~(-1)
11	Discharge Current High 1(A)	-105	(-900)~(-1)
12	Current Calibrate Enable	0	0~1
13	Min Current of SOC Calculate(A)	0.3	0~9.9

Num	Data Name	Value	Modify Ranges
14	Charge Calibrate 1		1~280
15	Charge Calibrate 2	-(Current calibration charge and discharge	1~280
16	Discharge Calibrate 1	parameters)	(-280)~(-1)
17	Discharge Calibrate 2		(-280)~(-1)
18	Total Current(A)	-	-

# Temperature


Num	Data Name	Value	Modify Ranges
0	Temp Diff Max 3(℃)	25	1~25
1	Temp Diff Max 2(℃)	15	1~25
2	Temp Diff Max 1(℃)	12	1~25
3	Charge Temp. High 3(℃)	55	35~65
4	Charge Temp. High 2(℃)	50	35~65
5	Charge Temp. High 1(℃)	45	35~65
6	Charge Temp. Low 3(℃)	-10	(-20)~10
7	Charge Temp. Low 2(℃)	-5	(-20)~10
8	Charge Temp. Low 1(℃)	0	(-20)~10
9	Discharge Temp. High 3(℃)	55	35~65
10	Discharge Temp. High 2(℃)	53	35~65
11	Discharge Temp. High 1(℃)	50	35~65
12	Discharge Temp. Low 3(℃)	-20	(-20)~10
13	Discharge Temp. Low 2(℃)	-15	(-20)~10
14	Discharge Temp Low 1(℃)	-5	(-20)~10

# **Network Information**

Num	Data Name	Value	Modify Ranges
0	Network Connection Status	0: 4G Connect 1: Wifi Connect 2: Disconnect(EnerLog Connection Status)	-
1	Server Address	47.57.139.213	'0'~'9'; 'A'~'Z'
2	Server Port	5279	'0'~'9'; 'A'~'Z'
3	Firmware Version	-(EnerLog Firmware Version)	'0'~'9'; 'A'~'Z'
4	WIFI Account	-(When connecting to the WIFI module, fill in the WIFI module account)	'0'~'9'; 'A'~'Z'
5	WIFI Password	-(When connecting to the WIFI module, fill in the WIFI module password)	'0'~'9'; 'A'~'Z'
6	СС	-(Fill in the verification code of the EnerLog)	'0'~'9'; 'A'~'Z'
7	4G Serial Number	-(Fill in the EnerLog serial number)	'0'~'9'; 'A'~'Z'


# 7.5.4 FAULT Page

- (1) Output the number of exported fault entries(1~64)
- (2) Click Reading
- (3) Observe the progress bar reaching 100%
- (4) Click Export



#### 7.5.5 PACK Page

The scroll bar allows you to view the voltage, temperature, and BMU version number of the battery cell.



# 7.6 Liability exemption

ATESS does not provide quality warranty services for:

- 1. Damage caused by improper use, maintenance or inspection of products that not in accordance with the provisions of this manual.
- 2. Damage caused by false installation of the manual maintenance switch(CB/ MCB).
- 3. Damage caused by using charging equipment that does not meet the standard or improper charging operation.
- 4. Parts not produced by ATESS, such as high-voltage harness, etc.5. The battery system is soaked or drown by water.
- 6. Damage caused by refitting, adding or disassembling battery system without permission of after-sales department or authorized service provider of ATESS.
- 7. Damage caused by the operation failure when battery is defective without the permission of ATESS after-sales department.
- 8. Damage caused by force majeure, such as earthquake, typhoon, flood, chemical pollution, lightning strike, hail, sediment, flying stone, fire, or considered intentional damage etc.

# Common troubleshooting 8

# 8.1 Fault and Abnormal State Processing

#### Appendix A

FAQ

- Q. After closing the POWER SW switch, the battery system has no output.
- A. Observe the status of the battery module and the BPU LED lamp;
- 1) If some of the cabinets are not lit, it is necessary to confirm whether the cabinet with the last LED light is connected to the next cabinet without the LED light and the communication line connected to all the cabinets without the LEDs is incorrect. Or missing the connection, or even the communication line is damaged;
- 2) If all the cabinets are not lit, it indicates that there is a problem with the power supply of the system. It is necessary to check whether the power line of the cabinet system is incorrectly wired or missing. If there is no error in the power wiring, then the BPU needs to be opened to check whether the power circuit is faulty.
- 3) If all the cabinet LED lights are on, you need to check the fault according to the battery module and the BPU indicator.
- Q. What should I do if the indicator light of the BPU shows the first level alarm, the second level protection, and the third level protection?
- A, 1) Level 1 alarm: The system is running normally without any action;
- 2) Two-level fault: the battery system has no action and the inverter is standby;
- 3) Three-level fault: The battery system cuts off the main circuit relay. Inverter shutdown
- 4) If there is a system failure, you can first view the fault type information on the operation data page on the inverter display, if the fault type information is viewed on the display of the battery system.

# 8.2 Battery Fault Table

Bx Active Balance Cur Failure Warning	
Bx Class2_CellVolt_High_Fault	
Bx Class2_CellVolt_Low_Fault	
Bx Class2_CellVolt_MaxDiff_Fault	
Bx Class2_ChargeCurr_High_Fault	Second level fault, X indicates the fault group that triggered it; the system can operate
Bx Class2_DisChargeCurr_High_Fault	normally
Bx Class2_TEMP_High_Fault	
Bx Class2_TEMP_Low_Fault	
Bx Class2_TEMP_MaxDiff_Fault	
Bx Class2_TotalVolt_High_Fault	
Bx Class2_TotalVolt_Low_Fault	
Bx BMU_SPI_Fault	
Bx Cell_Open_Fault	
Bx Class3_CellVolt_High_Protection	
Bx Class3_CellVolt_Low_Protection	
Bx Class3_CellVolt_MaxDiff_Protectio	1
Bx Class3_ChargeCurr_High_Protection	Level 3 protection, the battery group relay is
Bx Class3_Dis/ChargeCurr_HW_Protection	
Bx Class3_DisChargeCurr_High_Protectio	
Bx Class3_Master_Slave_ComFault	Xth battery group is kicked out of the system
Bx Class3_TEMP_High_Protection	and the system operates normally
Bx Class3_TEMP_Low_Protection	
Bx Class3_TEMP_MaxDiff_Protection	
Bx Class3_TotalVolt_High_Protection	
Bx Class3_TotalVolt_Low_Protection	
Bx Inverter_BMS_Lowvoltage_Protectio	ו
Bx Class4_TEMP_High_Protection	
Bx Fire Warning	
Bx Fire Warning  Bx InsulationLow_Fault	Level 4 protection: the entire system fails and all battery packs cannot operate normally
	Level 4 protection: the entire system fails and all battery packs cannot operate normally

Bx Smoke Sensor Warning		
Bx Temp Sensor Warning		
Bx KickOut System	The xth battery group is kicked out of the system due to a level 3 fault (the number of normal operating battery groups is greater than or equal to the minimum number of online groups)	
TotalVolt < 200V  Poweron_Timeout	If the total voltage is less than 200V or the BCU reads data more than 8 times in a row, this fault will be reported (alarm/relay will not close)	
TotalVoltDiffHigh_5	The total voltage difference of multiple parallel batteries is greater than 5V (the system relay does not close when powered on/the alarm is triggered during operation)	
Current Diff Over 10A Warning	The current difference of multiple parallel batteries is greater than	
PCS/HPS_Communication_Fault	10A	

# 8.3 Fault phenomenon and troubleshooting methods

#### 8.3.1 Communication failure with HPS

**Fault phenomenon:** The fault information page on the screen displays PCS/H -PS\_Communication\_Fault.

**Troubleshooting method:** This fault will be reported when the communication between MBMS and the inverter is lost.

**Reason 1:** The abnormality of the CAN communication line between MBMS and the inverter will cause communication failure;

**Reason 2**: The battery system is powered on, but the inverter is not powered on, so MBMS cannot communicate with the inverter, and the communication failure will be reported after a delay of 30 minutes.

**Solution**: Check whether the CAN communication line is connected correctly.

#### 8.3.2 Master-slave board communication failure

**Fault phenomenon:** The fault information page on the inverter screen displays Master-slave board comm failure (level 3).

**Troubleshooting method:** This fault will be reported if the communication between MBMS and BCU is lost.

**Reason 1:** The abnormality of the CAN communication line between MBMS and BCU will cause communication failure;

**Reason 2**: During the operation of the battery system, the BCU is kicked out by MBMS due to a level 3 fault. After the BCU is tripped, the communication between MBMS and BCU is disconnected, and the master-slave board communication fault will be reported.

**Solution:** Check whether the CAN communication line is connected correctly if the communication line is abnormal; the cause of the BCU fault tripping solves the BCU fault problem.


#### 8.3.3 BMU communication failure

Fault phenomenon: The fault information page on the screen displays Class3 BMU BCU ComFault.

Troubleshooting method: This fault will be reported when the communication between BCU and BMU is lost. Generally, the CAN communication line between BCU and BMS is abnormal, which will cause communication failure, or the CAN communication matching resistor value is not  $120\Omega$  (the CAN1 resistor dial is not set when replacing a new BCU). The location of the BMU with communication failure can be viewed on the battery pack Host page of the screen.

**Solution:** Communication line abnormality Check whether the CAN communication line is connected correctly; CAN1 resistance value is not correct Set the BCU CAN1 dial.





#### 8.3.4 Voltage sampling abnormality

**Fault phenomenon**: The fault information page on the screen shows low voltage fault, high voltage fault, and large voltage difference fault.

**Troubleshooting method:** Battery voltage abnormality is divided into BMU sampling abnormality and voltage collection harness abnormality. The battery PACK position with temperature fault can be viewed on the battery pack Host page of the screen. Battery voltage abnormality can be checked by swapping adjacent BMUs. After swapping BMUs, the fault position is the same, indicating a BMU fault; if the fault position changes, it indicates a battery voltage collection harness fault.

**Solution**: If BMU fails, replace the BMU; if the battery voltage collection harness fails, replace the battery voltage collection line.

#### 8.3.5 Temperature sampling abnormality

**Fault phenomenon:** The fault information page on the screen displays low temperature fault, high temperature fault, and temperature difference fault.

**Troubleshooting method:** Temperature abnormality is divided into BMU sampling abnormality and temperature sensor harness abnormality. The battery pack host page on the screen can view the location of the temperature fault battery PACK. Temperature abnormality can be checked by swapping adjacent BMUs. After swapping BMUs, the fault location is the same, indicating a BMU fault; if the fault location changes, it indicates a temperature sensor harness fault.

**Solution**: If BMU fails, replace the BMU; if the temperature sensor harness fails, replace the temperature sensor line.


#### 836 Abnormal current

**Fault phenomenon:** When the system is powered on, a level 3 fault is reported, and the screen shows abnormal current (as shown below).

**Troubleshooting method:** This is usually caused by a virtual connection problem of the current collection harness of the BPU. The location of the battery cluster with abnormal current can be confirmed through the battery cluster data page.

**Solution**: Disassemble the BPU and reconnect the current collection connectors at the BCU end and the current sensor end (as shown in the figure below).






#### 8.3.7 Active current balancing failure (REPT BMU has this function)

**Fault phenomenon:** The fault information page on the screen shows that the active balancing current fails.

**Troubleshooting method:** This fault is caused by failure of active balancing function. You can view the location of the faulty BMU on the battery pack Host page of the screen, find the corresponding BMU and measure whether the fuse on the active balancing relay board is damaged.

**Solution:** Replace the damaged fuse on the active balancing board or replace the active balancing relay board.






#### 8.3.8 Relay failure

**Fault phenomenon:** The fault information page on the screen displays PositiveRelay feedback Fault or NegitiveRelay feedback Fault.

**Troubleshooting method:** Measure whether the main contact and auxiliary contact feedback lines of the relay are conductive.


**Solution**: Relay adhesion treatment: Temporary method, you can try to knock the relay or supply 24V power to the relay to make the relay adhesion position fall off and return to normal; long-term method is to replace the relay.



#### 8.3.9 Insulation failure

**Fault phenomenon:** The fault information page on the screen displays Bx InsulationLow\_Fault.

Troubleshooting method: To troubleshoot insulation faults, first disconnect the battery input circuit breaker of the HPS or PBD to confirm whether the insulation value of the battery system is low or the insulation value of the photovoltaic system is low. The insulation value can be viewed on the battery pack Host page. The insulation is normal. The leakage voltage of the high-voltage positive and negative poles of the battery system to the battery rack is close to 0V. If there is an insulation problem in the battery pack, the positive and negative poles of the battery will have a leakage voltage to the battery rack (for example, 100V or higher). Insulation problems in the battery system



#### Battery rack leakage measurement:



Step1 Step2


## Battery PACK leakage measurement:



Step1 Step2

**Solution**: Insulate the battery leakage location and test whether the system insulation has returned to normal after treatment.

#### 8.3.10 parallel system total voltage difference 5V




**Fault phenomenon:** The fault information page on the screen shows a total voltage difference of 5V and a communication fault.

**Troubleshooting method:** This fault is caused by the total voltage difference between different battery clusters in the parallel system exceeding 5V.

**Solution**: The total voltage of the battery cluster needs to be adjusted through charging and discharging of the inverter; when the total voltage difference between the battery clusters is less than 5V, restart the system to resume normal operation.

#### 8.3.11 Abnormal SOC (large cell voltage difference)



Fault phenomenon: The SOC curve of the battery system drops abnormally. The SOC of the battery suddenly drops rapidly during normal discharge or suddenly rises rapidly during normal charging.

Troubleshooting method: The reason for SOC abnormality is poor battery consistency in the battery system, which can easily trigger SOC discharge calibration or charge calibration during the charge and discharge process. By analyzing the server historical data or analyzing and saving CAN communication data, you can find the location of the battery with abnormal voltage and confirm whether the battery system has poor battery consistency or capacity attenuation.

Solution: If the battery consistency is poor, recharge the battery; if the battery capacity is attenuated, replace the battery module; if the BMU sampling is abnormal, replace the BMU.

# 53

# 9 Annex

System inspection and Maintenance Checklist

No.	Category	Check item	Check method	Standard	Result	Problem description	Check frequency
_	Circuit BCeaker	Whether circuit BCeaker(CB) of DC Visual inspection CB all connected cabinet in parallel system trips	Visual inspection	CB all connected	□ Normal □ Abnormal		
7	maintenance	Whether DC Micro BCeaker(MCB) of Visual inspection MCB all connected BPU trips	Visual inspection	MCB all connected	□ Normal □ Abnormal		Olice two weeks
Μ		Software version	BMS data reading Record the or screen	Record the software version	□ Normal □ Abnormal		
4	Software	System alarm	BMS data reading or screen	No alarm in the alarm bar	☐ Normal ☐ Abnormal		
5	diagnostics	Battery consistency	The static BMS data reading differential or screen pressure sh	The static differential pressure shall be within 20mV	☐ Normal ☐ Abnormal		ע א העה אינה אינה אינה אינה אינה אינה אינה אינ
9		Whether the indoor or container ambient temperature is 20° C~ 40 ° C, and whether the temperature control equipment is in good condition	Thermometer	20° C~30° C	□ Normal □ Abnormal		
	System operation status and environment	Whether the temperature of battery module is normal, and whether the maximum temperature difference between modules is less than 5°C	BMS data reading or screen	<5° C	□ Normal □ Abnormal		Once two weeks
∞		whether the voltage of each cell in the system is normal, and whether the maximum voltage difference between each battery is less than 100mV	BMS data reading <100mV	<100mV	☐ Normal ☐ Abnormal		

No.	Category	Check item	Check method	Standard	Result	Problem description	Check frequency
0		Checkthefaultpageofthedisplayand check whether the battery system reports abnormal information	BMS data reading Nofaultrecord or screen	Nofaultrecord	□ Normal □ Abnormal		Once two weeks
10		Status of the air condition in container	Visual inspection, thermometer	25±3°C	☐ Normal ☐ Abnormal		
7		Whether the battery module and battery cabinet have abnormal sound or smell	Smell	No abnormal sound or smell	□ Normal □ Abnormal		
12	System cleaning	Is there water leakageor other foreign matter in the room or container	Visual inspection	No water leakage or foreign matters	☐ Normal ☐ Abnormal		Once two weeks
13		Whether there are rodents and insects such as mice, geckos, cockroaches and ants in the room	Visual inspection	No animals or insects	□ Normal □ Abnormal		
14		DC cable connection between Visualinspection battery boxes // thermometer		No obvious heating or temperature below 70 ° C	□ Normal □ Abnormal		
15	Circuit connection	Circuit connection between battery boxes / BMS fault record		No CAN communication fault	□ Normal □ Abnormal		Once two weeks
16		External power supply input connection of high voltage box	Visual inspection, recommended to take pictures	AC circuit BCeaker remains closed	☐ Normal ☐ Abnormal		
17		VoltageStack Battery ground Visualinspection, connection		<=4Ω	□ Normal □ Abnormal		

o N	Category	Check item	Check method	Standard	Result	Problem description	Check frequency
18	Circuit BCeaker	Check whether the power cable plug is loose or not tightened, and whether Visual inspection No damage the power cord surface is damaged	Visual inspection	No damage	☐ Normal ☐ Abnormal		
19	maintenance	Check whether the plug of communication cable is loose or not tightened, and whether the surface of communication cable is BCoken	Visual inspection	No loose or fracture	☐ Normal ☐ Abnormal		Once two weeks
20		Check the fan blades for ccabinets Visual inspection		No ccabinet on blade	□ Normal □ Abnormal		
21	Fan maintenance and replacement	Listen to whether there is abnormal viBCation sound when the fan is running	Hear,spanner, screwdriver, etc	No abnormal sound	□ Normal □ Abnormal		Once two weeks
22		If the fan has any abnormal condition, it shall be replaced in time	Visual inspection No abnormality	No abnormality	☐ Normal ☐ Abnormal		
23		Is the indoor or container lighting Visual inspection Normal lighting system in good condition	Visual inspection	Normal lighting	□ Normal □ Abnormal		
24	System operat status and environment	ion Is there any fault in the DC cabinet or BPU in the parallel system or Visual inspection record record	Visual inspection	No red light flashing in fault record	☐ Normal ☐ Abnormal		Once two weeks
25		Fire fighting facilities in good Visualinspection facilities not expired	Visual inspection		□ Normal □ Abnormal		